


# 1 Your mobile .....



- 1 Sub-display <sup>(1)</sup>
- 2 Volume up
- 3 Play/Pause key
- 4 Volume down
- 5 Left softkey
- 6 Pick up/Send call
- 7 Call memory
- 8 Voicemail
- 9 Right softkey
- 10 Switch on/Switch off
- 11 End call
- 12 Vibration alert
- 13 Navigation key <sup>(1)</sup>:
- 14 Menu/Confirm an option
- 15 Messages ▲
- 16 Directory ▼
- 17 WAP ◀
- 18 File manager ▶

## 1.1 Keys

- Navigation key  
Confirm an option (press the middle of the key)  
Access slide show and music player (long keypress)
- Pick up  
Send a call  
Access call memory (Redial) (short keypress)  
Access events (long keypress)
- Switch on/Switch off the telephone (long keypress)
- End call
- Return to the main screen
- Left softkey
- Right softkey
- Access your voicemail (long keypress)
- In Edit mode:
  - Short keypress: change input methods
  - Switch from T9 predictive mode to Normal mode
  - Long keypress: access the Symbols table
- In Edit mode:
  - Short keypress: access the language list
  - Long keypress: enter zero
- From main screen
  - Short keypress: #
  - Long keypress: activate/deactivate the vibrator
- In edit mode:
  - Short keypress: ␣ (space)
  - Long keypress: add a word
- Short keypress: Play/pause music, Radio off.  
Long keypress: Lock/Unlock the side keys (flip off).
- Short keypress: Previous/next song (in the playing mode)  
Previous/next channel (Radio on)  
Long keypress: Volume up/down

1

# 6 Messages .....



## 6.1 Create message

From the main menu select "Messages" to create text/multimedia message. You can type a message and you can also modify a predefined message in **Templates** or customise your message by adding pictures, photos, sounds, titles, etc (only available while editing a MMS). While writing a message, select "Options" to access all the messaging options. You can save your messages that you send often to **Drafts** or **Templates** (MMS only).

## 6.2 Inbox

All received messages (read and unread) are stored in the same Inbox.

# 7 My settings .....



From the main screen, select the icon menu and select the function of your choice in order to customise your telephone: Color, Theme, Clamshell, Equalizer, Display, Clock, Keys, More settings...

# 8 Tools .....



**8.1 Bluetooth**  
Access this feature by selecting "Tools" from the main menu, then "Bluetooth".

## 8.2 Organizer

Once you enter this menu from "Tools", there is a monthly-view calendar for you to keep track of important meetings, appointments, etc. Days with events entered will be marked in color.

7

# 9 WAP .....



Access Wap options: Homepage, Bookmarks, Recent pages, Go to URL and Profiles.

8

## 1.2 Main screen icons

- Battery charge level**
- Vibrate alert:** your phone vibrates, but neither rings nor beeps except for the alarms.
- Bluetooth status** (Blue - Activated).
- Bluetooth status** (Connected to an audio device).
- Headset connected.**
- Call forwarding activated:** your calls are forwarded.
- Alarm clock programmed.**
- Level of network reception.**
- Voicemail message arrived.**
- Unanswered calls.**
- WAP alerts <sup>(1)</sup>.**
- Roaming.**
- Memory card scanning in progress.**
- Memory card scanning completed.**
- Line switching <sup>(1)</sup>:** indicates the selected line.
- GPRS connection status** (Blue - Activated).
- Shown only in no ciphering mode while calling, sending/receiving SMS.
- Multimedia player active.**
- USB cable connected.**
- Reception of a message in progress.**
- Sending a message.**
- Silence mode:** your phone neither rings, beeps nor vibrates except for the alarms.
- Message unread**
- Message list is full:** your terminal cannot accept any new messages. You must access the message list and delete at least one message on your SIM card.
- Antenna off mode.**
- A2DP connected.**

<sup>(1)</sup> Contact your network operator to check service availability.

2

# 10 File manager .....



You will have an access to all audio and visual files stored in phone or memory card in File manager.

## 10.1 My audios

Choose an audio for the ON/OFF screen, for an incoming call, a message alert, power on/off ringtone or an alarm and scheduler.

## 10.2 My images

You can select an image or a photo as wallpaper, ON/OFF screen, or assign it to a contact in the directory.

## 10.3 My videos

The "My videos" album contains all video clips embedded and downloaded in phone or memory card.

## 10.4 My creations

This feature stores all the photos captured by your mobile phone.

## 10.5 Unknown files

Store files of unsupported format.

## 10.6 Memory card


You will have access to all files stored in memory card here.

3


# 2 Getting started .....

## 2.1 Set-up

### Removing and installing the back cover



### Installing and removing the battery



### Inserting and removing the SIM Card



Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press it and slide it out. Please power off your phone before you remove the SIM card.


## 2.2 Power on your phone

Hold down the key until the telephone powers on.

## 2.3 Power off your phone

Hold down the key from the main screen.

### Insert the memory card



To release the microSD card holder, slide it in the direction of the arrow and lift it. Then insert the microSD card with the golden contact downward. Finally, turn down the microSD holder and slide it in the opposite direction to lock it.

## 10.7 Formats and compatibility

- Sounds: mp3, m4a, aac, midi, wav, amr
- Images: jpg, gif, bmp
- Videos: 3gp, mjpg

# 11 Camera .....



Your mobile phone is fitted with a camera for taking photos and shooting videos that you can use in different ways:

- store them in your "File manager".
- send them in a multimedia message (MMS) to a mobile phone or an email address.
- customise your main screen.
- select them as incoming call image to a contact in your directory.
- transfer them by data cable or microSD card to your computer.
- modify your photos through adding frames.

# 12 Multimedia player .....



Access this feature from the main menu by selecting "Multimedia player". You will have full access to "Music player", "Video player", "Image viewer" and "FM radio".

9

# 3 Calls .....

## 3.1 Making a call

Dial the desired number then press the key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the right softkey.

To hang up the call, press the key.

### Making an emergency call

If your phone is covered by the network, dial emergency number and press the key to make an emergency call. This works even without a SIM card and without typing the PIN code or unlocking the keypad.

## 3.2 Calling your voicemail <sup>(1)</sup>

To access your voicemail, hold down the key.

## 3.3 Receiving a call

When you receive an incoming call, press the key to talk and then hang up using the key.

## 3.4 Available functions during the call

During a call, you can use your directory, your diary, short messages, etc. without losing your correspondent by pressing the key.

<sup>(1)</sup> Contact your network operator to check service availability.

4

# 4 Call register .....



## 4.1 Call memory

You can access your call memory by pressing the key from the main screen.

## 4.2 Events

By holding down the key from main screen or accessing from main menu, it allows you to view a list of your all latest 20 events (SMS, MMS, WAP Alerts, Voicemail and unanswered calls).

## 4.3 Billing

You can access different items with this option: Amount, Duration, GPRS counter, Beep duration.

## 4.4 Call settings

You can access a number of items with this option: Call waiting, Call forwarding, Call barring, Caller ID, Line switching, Auto redial.

# 5 Directory .....



## 5.1 Consulting your directory

To access the **directory** from the main screen, press the key or press the key and select the icon from the menu.

## 5.2 Creating a file

Select the directory in which you wish to create a file, press the "Options" softkey, select "Create file" then .

6

# 13 Games & Applications .....



Your Alcatel phone may include<sup>(1)</sup> some Java™ applications and games. You can also download new applications and games to your phone.

# 14 Profiles .....



With this menu, you may personalise ringtones for different events and environments.

# 15 Making the most of your mobile .....

PC suite is provided on [www.missixty.com](http://www.missixty.com).

You can download software upgrade for free from this website.

# 16 Latin input mode .....

To write messages, there are two writing methods:

- Normal: this mode allows you to type a text by choosing a letter or a sequence of characters associated with a key.
- Predictive with the T9 mode: this mode speeds up the writing of your text.
- key in edit mode:
  - Short keypress: Access the language list
  - Long keypress: Enter zero

<sup>(1)</sup> Depending on your country or your operator.

10

ALCATEL is a trademark of Alcatel-Lucent and used under license by TCT Mobile Limited.

All rights reserved © Copyright 2009 TCT Mobile Limited.

TCT Mobile Limited reserves the right to alter material or technical specification without prior notice.

Prolonged exposure to music at full volume on the music player may damage the listener's hearing. Set your phone volume safely. Use only headphones recommended by TCT Mobile Limited and its affiliates.

11

12

