Ouick Start Guide

For more information about how to use the phone, please go to www.alcatelonetouch.com to download complete user manual (English version only). Moreover, from the website you can also consult FAO (English version only).



This product meets applicable national SAR limits of 2.0 W/kg. The specific maximum SAR values can be found on page 21 of this user guide.

When carrying the product or using it while worn on your body, either use an www.sar-tick.com approved accessory such as a holster or otherwise maintain a distance of 10 mm from the body to ensure compliance with RF exposure requirements. Note that the product may be transmitting even if you are not making a phone call.

PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker

6 Switch on/Switch off

ALCATELONetouch

Your mobile.....

O Vibration alert

Navigation key:

Messages A

Profiles 4

(press and hold)

Menu/Confirm an option



I.I Keys

Navigation key Confirm an option (press the middle of the key)

Pick up/Send a call

In idle screen:



Return to idle screen

Left softkey Right softkey

Access your voicemail (press and hold)

- Press: access the symbols table

- Press and hold: enter zero

- Press: change input methods - Press and hold: access the language list

- In idle screen: - Press:

- Press and hold: activate/deactivate the vibrate mode

In Edit mode:

- Press: - (space)

I.2 Main screen icons (1)

Vibrate alert: your phone vibrates, but does not ring

Call forwarding activated: your calls are forwarded.

Silence mode: your phone does not ring, beep or

The icons and illustrations in this guide are provided for information

vibrate with the exception of the alarm

Alarm or appointments programmed.

Level of network reception.

Voicemail message arrived.

In 1030X:

Battery charge level.

Headset connected

SIM card missing

SMS unread.

Flight mode

वन्ति Level of network reception

In 1030D:

Call forwarding activated: your calls are

SMS unread.

Getting started.....

Removing and installing the back cover



Removing and installing the battery







Place the SIM card with the chip facing downwards and slide it into its housing. Make sure that it is correctly inserted. To remove the card, press it and slide it out.

Inserting and removing the SIM card

Charging the battery



Connect the battery charger to your phone and mains socket

- · The charging may take about 20 minutes to start if the
- Be careful not to force the plug into the socket.
- Make sure the battery is correctly inserted before connecting the charger.
- The mains socket must be near to the phone and easily accessible (avoid electric extension cables). When using your telephone for the first time, charge the
- battery fully (approximately 3 hours). You are advised to fully charge the battery ().
- To reduce power consumption and energy waste, when battery is fully charged, disconnect your charger from the plug; reduce the backlight time, etc.



The charge is complete when the animation stops.

2.2 Power on your phone

Hold down the ____ key until the phone powers on.

2.3 Power off your phone

Hold down the Wey from the main screen.

Calls

3.1 Making a call

Dial the desired number then press the ___ key to place the call. If you make a mistake, you can delete the incorrect digits by pressing the right softkey.

To hang up the call, press the ____ key

Making an emergency call

If your phone is covered by the network, dial emergency number and press the key to make an emergency call. This works even without a SIM card and without typing the

3.2 Calling your voicemail (1)

To access your voicemail, hold down the weekey.

3.3 Receiving a call

When you receive an incoming call, press the Lee key to talk and then hang up using the ____ key.

3.4 Available functions during the call

During a call, you can use your directory, your calendar, short messages, etc. without losing your correspondent.

Contact your network operator to check service availability.

Contacts.....

4.1 Consulting your contacts

To access the **Contacts** from the main screen, press the key and select the 🔲 icon from the menu.

For dual SIM model, the complete contacts of both SIM1 and SIM2 are available in this menu (1)

4.2 Adding a contact

You can add a new contact to phone or SIM card by selecting "Add contact".

Messages

5.1 Create message

From the main menu select "Messages" to create text message. You can type a message and you can also modify a predefined message in **Templates**. While writing a message, select "Options" to access all the messaging options. You can save your messages that you send often to Drafts.



Specific letters (accent) will increase the size of the SMS, this may cause multiple SMS to be sent to your recipient.

Left softkey

O Voicemail

Pick up/Send call

Right softkey



You can access the function using the following options:

Select A from main menu

• Press the send key from Home screen 6.2 Available options

When you press "Options", you can have access to View. Send SMS, Save to Contacts, Edit before call, Add to blacklist. Add to whitelist. Delete etc.



Music.....



Access this feature from the main menu by selecting "Music" You will have full flexibility of managing music on memory card. Make sure your memory card well inserted before activating

FM radio.....

Your phone is equipped with a radio (1) with RDS functionality. You can use the application as a traditional radio with saved channels or with parallel visual information related to the radio program on the display if you tune to stations that offer Visual Radio service. You can listen to it while running other



My files

You will have access to all audio and visual files stored in memory card in My files. You can access a number of items with this option: My audios, My images, My videos, Other

Inserting and removing the memory card:



To insert the microSD card with the golden contact downward. To remove the card, press and slide it out.

The quality of the radio depends on the coverage of the radio station in that particular area.



From the main menu, select the menu icon and select the function of your choice in order to customise your telephone: Phone settings, Call settings, Security, Network, Restore default, Dual SIM switch(1), Dual SIM settings(1).



Your mobile phone has a built-in alarm clock with a snooze

Enter a number, select the type of operation to be performed, and enter the second number, then press "=" to display the

11.3 Calendar

Once you enter this menu from the main menu, there is a With this menu, you may personalise ringtones for different monthly-view calendar for your view.

11.4 Voice alarm

With this menu, you may create the voice file and set it as the

You can create a note in text format by accessing "Tools\ Notes" from the main menu.

11.6 Call filter

Enable blacklist, all callers in the list will be automatically blocked. Enable whitelist, only callers in the list can be connected. You are allowed to add 50 contacts to each list from Contacts, Call log, Messages or to add directly by pressing

11.7 Services

events and environments

Contact your network operator to check service availability.







your mobile

ONE TOUCH Upgrade

Using ONE TOUCH Upgrade tool you can update your phone's software from your PC.

Download ONE TOUCH Upgrade from ALCATEL ONE TOUCH website (www.alcatelonetouch.com) and install it on your PC. Launch the tool and update your phone by following the step by step instructions (refer to the User Guide provided together with the tool).

Your phone's software will now have the latest software.



All personal information will be permanently lost following the update process. We recommend you backup your personal data before upgrading.

Making the most of 4 Latin input mode...

To write messages, there are two writing methods:

- Normal: this mode allows you to type a text by choosing a letter or a sequence of characters associated with a key.
- Predictive with the eZi mode: this mode speeds up the writing of your text.
- + kev in edit mode

Press: access the symbols table Press and hold: enter zero

All rights reserved © Copyright 2013 TCT Mobile Limited.

ALCATEL is a trademark of

Alcatel-Lucent and used under license by

TCT Mobile Limited.

TCT Mobile Limited reserves the right to alter material or technical specification without prior notice

PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.

(I) 1030D only. English - CJB26G0ALAAA

2013-4-26 10:09:02

IP4545_1030X_1030D_QG_Eng_GB_12_130426.indd 1

We recommend that you read this chapter carefully before using your phone. The manufacturer disclaims any liability for damage, which may result as a consequence of improper use or use contrary to the instructions contained herein

TRAFFIC SAFETY

Given that studies show that using a mobile phone while driving a vehicle constitutes a real risk, even when the hands-free kit is used (car kit, headset...), drivers are requested to refrain from using their mobile when the vehicle is not parked

When driving, do not use your phone and headphone to listen to music or to the radio. Using a headphone can be dangerous and forbidden in some areas

When switched on, your phone emits electromagnetic waves that can interfere with the vehicle's electronic systems such as ABS antilock brakes or airbags. To ensure that there is no problem:

- do not place your phone on top of the dashboard or within an airhag denloyment area
- check with your car dealer or the car manufacturer to make sure that the dashboard is adequately shielded from mobile phone RF

CONDITIONS OF USE:

You are advised to switch off the telephone from time to time to optimise its performance.

Switch the phone off before boarding an aircraft

Switch the phone off when you are in health care facilities, except in designated areas. As with many other types of equipment now in regular use, mobile telephones can interfere with other electrical or electronic devices, or equipment using radio frequency.

Switch the phone off when you are near gas or flammable liquids. Strictly obey all signs and instructions posted in a fuel depot, petrol station, or chemical plant, or in any potentially explosive

When the phone is switched on, it should be kept at least 15 cm from any medical device such as a pacemaker, a hearing aid or insulin pump, etc. In particular when using the phone, you should hold it against the ear on the opposite side to the device, if any.

To avoid hearing impairment, pick up the call before holding your phone to your ear. Also move the handset away from your ear while using the "hands-free" mode because the amplified volume might cause hearing damage.

LICENCES

zicorporation Corporation and/or its Affiliates.

IP4545 1030X 1030D QG Eng GB 12 130426.indd 2

Do not let children use the phone and/or play with the telephone and accessories without supervision

When replacing the cover please note that your phone may contain substances that could create an allergic reaction

Always handle your phone with care and keep it in a clean and dust-free

Do not allow your phone to be exposed to adverse weather or ironmental conditions (moisture, humidity, rain, infiltration of liquids, dust, sea air, etc). The manufacturer's recommended operating temperature range is -10°C to +55°C.

Over 55°C the legibility of the phone's display may be impaired, though this is temporary and not serious.

Emergency call numbers may not be reachable on all cellular networks. You should never rely only on your phone for emergency calls. Do not open, dismantle or attempt to repair your mobile phone

Do not drop, throw or bend your mobile phone.

Use only batteries, battery chargers, and accessories which are recommended by TCT Mobile Limited and its affiliates and are mpatible with your phone model. TCT Mobile Limited and its affiliates disclaim any liability for damage caused by the use of other chargers or batteries

Remember to make back-up copies or keep a written record of all important information stored in your phone.

me people may suffer epileptic seizures or blackouts when exposed to flashing lights, or when playing video games. These seizures or blackouts may occur even if a person never had a previous seizure or blackout. If you have experienced seizures or blackouts, or if you have a family history of such occurrences, please consult your doctor before playing video games on your phone or enabling a flashing-lights feature on your phone.

Parents should monitor their children's use of video games or other features that incorporate flashing lights on the phones. All persons should discontinue use and consult a doctor if any of the following symptoms occur: convulsion, eye or muscle twitching, loss of awareness, involuntary movements, or disorientation. To limit the likelihood of such symptoms, please take the following safety

- Do not play or use a flashing-lights feature if you are tired or need
- Take a minimum of a 15-minute break hourly
- Play in a room in which all lights are on.

Play at the farthest distance possible from the screen

If your hands, wrists, or arms become tired or sore while playing stop and rest for several hours before playing again.

If you continue to have sore hands, wrists, or arms during or after playing, stop the game and see a doctor.

When you play games on your phone, you may experience occasional discomfort in your hands, arms, shoulders, neck, or other parts of your hody. Follow the instructions to avoid problems such as tendinitis carnal tunnel syndrome or other musculoskeletal disorders

PROTECT YOUR HEARING

To prevent possible hearing damage, do not listen at high volume levels for long periods. Exercise caution when holding your device near your ear while the loudspeaker is in use.

se note that you must respect the laws and regulations in force in your jurisdiction or other jurisdiction(s) where you will use your phone regarding taking photographs and recording sounds with telephone. Pursuant to such laws and regulations, it may ly forbidden to take photographs and/or to record the voices per people or any of their personal attributes, and duplicate or bute them, as this may be considered to be an invasion of privacy is the user's sole responsibility to ensure that prior authorisation be ined, if necessary, in order to record private or confidential versations or take a photograph of another person; the perator) disclaim any liability which may result from the imprope

BATTEDY.

Before removing the battery from your phone, please make sure that the phone is switched off

Observe the following precautions for battery use Do not attempt to open the battery (due to the risk of toxic fumes and

- Do not puncture, disassemble or cause a short-circuit in a battery.
- Do not burn or dispose of a used battery in household rubbish or store it at temperatures above 60°C

Batteries must be disposed of in accordance with locally applicable environmental regulations. Only use the battery for the purpose for which it was designed. Never use damaged batteries or those not recommended by TCT Mobile Limited and/or its affiliates.

Telephone warranty

Your phone is warranted against any defect or malfunctioning which may occur in conditions of normal use during the warranty period of twelve (12) months (1) from the date of purchase as shown on your original invoice.

Batteries (2) and accessories sold with your phone are also six (6) months (1) from the date of purchase as shown on your

> In case of any defect of your phone which prevents you from normal use thereof, you must immediately inform your vendor and present your phone with your proof of purchase.

> If the defect is confirmed, your phone or part thereof will be either replaced or repaired, as appropriate. Repaired Phone and accessories are entitled to a one (1) month warranty for the same defect. Repair or replacement may be carried out using reconditioned components offering equivalent functionality.

> This warranty covers the cost of parts and labor but excludes any other costs

The warranty period may vary depending on your country.

The life of a rechargeable mobile phone battery in terms of conversatio time standby time, and total service life, will depend on the conditions of use and network configuration. Batteries being considered expendable supplies, the specifications state that you should obtain optimal performance for your phone during the first six months after purchase and for approximately 200 more recharges.

I) Non-compliance with the instructions for use or installation, or with technical and safety standards applicable in the

2) Connection to any equipment not supplied or not recommended by TCT Mobile Limited.

warranted against any defect which may occur during the first 3) Modification or repair performed by individuals not authorised by TCT Mobile Limited or its affiliates or your

> liquids or foods, chemical products, download of files, crash, high voltage, corrosion, oxidation

> There are no express warranties, whether written, oral or

implied, other than this printed limited warranty or the mandatory warranty provided by your country or jurisdiction.

liable for indirect, incidental or consequential damages of any nature whatsoever, including but not limited commercial or financial loss or damage, loss of data or loss of image to the full extent those damages can be disclaimed by law.

Some countries/states do not allow the exclusion or limitation of indirect, incidental or consequential damages, or limitation of the duration of implied warranties, so the preceding limitations or exclusions may not apply to you.

The radio wave exposure guidelines use a unit of measurement known For more information you can go to www.alcatelonetouch.com as the Specific Absorption Rate or SAR The SAR limit for mobile devices is 2.0 W/kg

Tests for SAR are conducted using standard operating positions with the device transmitting at its highest certified power level in all tested frequency bands. The highest SAR values under the ICNIRP guidelines for this device model are: 1030X

Maximum SAR for this model and conditions under which it was

	recorded.			
	Head SAR	GSM 900	0.968 W/kg	
	Body-worn SAR	GSM 900	0.529 W/kg	

Maximum SAR for this model and conditions under which it was recorded.		
Head SAR	GSM 900	0.968 W/kg
Body-worn SAR	GSM 900	0.529 W/kg

During use, the actual SAR values for this device are usually wel below the values stated above. This is because, for purposes of system efficiency and to minimize interference on the network, the operating power of your mobile device is automatically decreased when t power is not needed for the call. The lower the power output of the device, the lower its SAR value.

Body-worn SAR testing has been carried out at a separation distance of 10 mm. To meet RF exposure guidelines during body-worn operation, the device should be positioned at least this distance away from the body. If you are not using an approved accessory ensure that whatever product is used is free of any metal and that it positions the phone the indicated distance away from the body. The World Health Organization has stated that present scientific

information does not indicate the need for any special precautions for the use of mobile devices. They recommend that if you are interested in further reducing your exposure then you can easily do so by limiting your usage or simply using a hands-free kit to keep the device away from the head and body

Additional information about electromagnetic fields and public health

Your telephone is equipped with a built-in antenna. For optimal

are available on the following site: http://www.who.int/peh-emf

Regulatory information..

The following approvals and notices apply in specific regions as





TCT Mobile Europe SAS - Siège social : 55 Avenue des Champs Pierreux, Immeuble Le Capitole 92000 Nanterre Fr

10300

TCTMobile



TCT Mobile Europe SAS - Siège social : 55 Avenue des Champs Pierreux, Immeuble Le Capitole 92000 Nanterre Fr

Troubleshooting.....

Before contacting the service centre, you are advised to follow the instructions below

Avoid storing large amounts of data in your phone as this may affect its performance

be lost permanently. It is strongly advised to fully backup the phone data and profile before doing formatting and upgrading. and carry out the following checks:

then turn your phone on

Check the battery power level, charge for at least 20 minutes

My phone is frozen or has not responded for several

Restart your phone by pressing and holding the week Remove the battery and re-insert it, then restart the phone

the phone or ONE TOUCH Upgrade to upgrade software (1) My phone turns off by itself

Check the battery charge level

If it still does not work, please use User Data Format to reset

My phone cannot charge properly

Make sure you are using an ALCATEL ONE TOUCH battery and the charger from the box

Clean the battery contact if it's dirty.

Make sure your battery is inserted properly before plugging in the charger Make sure that your battery is not completely discharged; if

the battery power is empty for a long time, it may take around 20 minutes to display the battery charger indicator on the Make sure charging is carried out under normal conditions

(0°C to +40°C) When abroad, check that the voltage input is compatible

My phone cannot connect to a network or "No service" s displayed

Try connecting in another location Verify the network coverage with your operator

Check with your operator that your SIM card is valid

 Try selecting the available network(s) manually Try connecting at a later time if the network is overloaded

Invalid SIM card

Make sure the SIM card has been correctly inserted Make sure the chip on your SIM card is not damaged or

scratched Make sure the service of your SIM card is available

Unable to make outgoing calls

Make sure you have dialed a valid number and press the

· For international calls, check the country and area codes Make sure your phone is connected to a network, and the

network is not overloaded or unavailable Check your subscription status with your operator (credit, SIM card valid, etc.)

Make sure you have not barred outgoing calls Make sure that your phone is not in flight mode

Unable to receive incoming calls

 Make sure your phone is switched on and connected to a network (check for overloaded or unavailable network)

Check your subscription status with your operator (credit, SIM card valid, etc.)

Make sure you have not forwarded incoming calls Make sure that you have not barred certain calls

Make sure that your phone is not in flight mode The caller's name/number does not appear when a call

is received Check that you have subscribed to this service with your

operator Your caller has concealed his/her name or number

I cannot find my contacts

Make sure your SIM card is not broken Make sure your SIM card is inserted properly

Import all contacts stored in SIM card to phone

The sound quality of the calls is poor You can adjust the volume during a call by pressing the hey

Check the network strength

Make sure that the receiver, connector or speaker on your phone is clean

I am unable to use the features described in the manual • Check with your operator to make sure that your subscription

includes this service Make sure this feature does not require an ALCATEL ONE TOUCH accessory

When I select a number from my contacts, the number cannot be dialed

· Make sure that you have correctly recorded the number in your file

Make sure that you have inputted the country prefix when calling a foreign country

I am unable to add a contact in my contacts

some files from your SIM card or save the files in the phone My callers are unable to leave messages on my

· Contact your network operator to check service availability

I cannot access my voicemail

entered in "Messages\Voicemail" Try later if the network is busy

The flickering icon is displayed on my standby

Contact your network operator to obtain the PUK code (Personal Unblocking Key)

Make sure that you're using the right cable from the box

How to make your battery last longer

After a partial charge, the battery level indicator may not be exact. Wait for at least 20 minutes after removing the

Switch on the backlight upon request

User Data Format ALL user phone data: Contacts, messages and files will be lost permanently. Please store phone data in SIM card before you want to format







eZiText™

microSD Logo is a trademark.

eZiText™ and Zi™ are trademarks of Zi

General information......

Internet address: www.alcatelonetouch.com Hot Line Number: see "TCT Mobile Services" leaflet or go to our Internet site. Address: Room 1910-12A, Tower 3, China HK City, 33

Canton Road, Tsimshatsui, Kowloon, Hong Kong On our Internet site, you will find our FAO (Frequently Asked Questions) section. You can also contact us by e-mail to ask any

An electronic version of this user guide is available in English and other languages according to availability on our server: www.

Your telephone is a transceiver that operates on GSM networks

with 900 and 1800 MHz bands. CE1588

Protection against theft (1)

questions you may have.

This equipment is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The entire copy of the Declaration of Conformity for your telephone can be obtained through our website: www.alcatelonetouch.com

Your telephone is identified by an IMEI (phone serial number) shown

on the packaging label and in the product's memory. We recommend

that you note the number the first time you use your telephone by

allows your mobile telephone to be blocked preventing a third

person from using it, even with a different SIM card.

entering * # 0.6 # and keep it in a safe place. It may be requested by the police or your operator if your telephone is stolen. This number

There may be certain differences between the user manual description and the phone's operation, depending on the software release of your telephone or specific operator

TCT Mobile shall not be held legally responsible for such differences, if any, nor for their potential consequences, which responsibility shall be borne by the operator exclusively. Contact your network operator to check service availability.

Due to different applicable electrical specifications, a charger you purchased in one jurisdiction may not work in another jurisdiction. They should be used for this purpose only. RADIO WAVES:

Proof of compliance with international standards (ICNIRP) or with European Directive 1999/5/EC (R&TTE) is required of all mobile phone models before they can be put on the market. The protection of the health and safety for the user and any other person is an essential requirement of these standards or this directive THIS DEVICE MEETS INTERNATIONAL GLIDELINES FOR EXPOSI IRE TO RADIO WAVES

This symbol on your telephone the battery and the

collection points at the end of their life.

They will then be recycled, preventing substances being disposed of in

All products with this sign must be brought to these collection points.

Items of equipment with this symbol are not to be thrown into

ordinary bins if your jurisdiction or your region has suitable recycling

CAUTION: RISK OF EXPLOSION IF BATTERY IS REPLACED BY

AN INCORRECT TYPE, DISPOSE OF USED BATTERIES

Mains powered chargers will operate within the temperature range of:

The chargers designed for your mobile phone meet with the standard

for safety of information technology equipment and office equipment

use. They are also compliant to the ecodesign directive 2009/125/EC.

and collection facilities; instead they are to be taken to collection

- Collection bins at points of sale

the environment, so that their components can be reused.

These collection points are accessible free of charge.

these items of equipment

In European Union countries:

points for them to be recycled.

CHARGERS

0°C to 40°C

In non European Union jurisdictions:

ACCORDING TO THE INSTRUCTIONS.

accessories means that these products must be taken to

Municipal waste disposal centres with specific hins for

Your mobile device is a radio transmitter and receiver. It is designed not to exceed the limits for exposure to radio waves (radio frequency electromagnetic fields) recommended by international guidelines. The guidelines were developed by an independent scientific organization (ICNIRP) and include a substantial safety margin designed to assure the safety of all persons, regardless of age and health.

This warranty shall not apply to defects to your phone and/or accessory due to (without any limitation):

geographical area where your phone is used.

4) Inclement weather, lightning, fire, humidity, infiltration of

Your phone will not be repaired in case labels or serial numbers (IMEI) have been removed or altered.

In no event shall TCT Mobile Limited or any of its affiliates be

You are advised to fully charge () the battery for optimal

 Use User Data Format and the ONE TOUCH Upgrade tool to perform phone formatting or software upgrading, (to perform User Data format, hold down # key while simultaneously pressing the power on/off key under power off mode). ALL User phone data: contacts, messages and files will

My phone cannot switch on Check the battery contacts, remove and reinstall your battery

If it still does not work, please use User Data Format to reset the phone or ONE TOUCH Upgrade to upgrade software (1)

If it still does not work, please use User Data Format to reset

Make sure power off key is not mis-contacted

the phone or ONE TOUCH Upgrade to upgrade software (

operation, you should avoid touching it or degrading it. As mobile devices offer a range of functions, they can be used in positions other than against your ear. In such circumstances the device will be compliant with the guidelines when used with headset or USB data cable. If you are using another accessory ensure that whatever product is used is free of any metal and that it positions the phone at least 10 mm away from the body.

Make sure that your SIM card contacts are not full; delete

Make sure your operator's voicemail number is correctly

You have saved too many short messages on your SIM card:

delete some of them or archive them in the phone memory SIM card PIN locked

I am unable to connect my phone to my computer

Make sure you follow the complete charge time (minimum

charger to obtain an exact indication

2013-4-26 10:09:03