

# Infinix



ALPHA **Marvel**



---

User Guide / Manuel d'utilisation / دليل المستخدم

1. Getting to know the phone.....	1
1.1 Battery.....	2
1.2 SIM card.....	3
1.3 Home Screen.....	5
1.4 Notifications panel.....	6
2. Call functions.....	8
2.1 Voice and video calls.....	8
2.2 Accept or reject a call.....	9
2.3 Use flight mode.....	10
3. Contact.....	10
3.1 Copy contacts from your SIM card.....	11
3.2 Create contact information.....	11
3.3 Find contact information.....	11
3.4 Edit contact information.....	11
3.5 Backup contacts via mobile phone.....	12
3.6 Manage Group.....	12
4. SMS.....	14
4.1 SMS and MMS.....	14
4.2 E-mail.....	15
5. Establishing a connection.....	17
5.1 Mobile Network.....	17
5.2 Use Wireless local area network.....	18
5.3 Browse the Internet.....	29

5.4 Use Bluetooth.....	20
6. Entertainment features.....	21
6.1 Photograph and camera.....	21
6.2 Use the Gallery.....	24
6.3 Enjoy the music.....	25
7. Accounts and sync.....	26
7.1 Manage accounts.....	27
7.2 Custom account synchronization information.....	27
8. More applications.....	28
8.1 Calendar.....	28
8.2 Use the clock.....	29
9. Manage cell phone.....	31
9.1 Display settings.....	31
9.2 Profile settings.....	32
9.3 Set the text to speech.....	33
9.4 Security settings.....	33
9.5 Management applications.....	34
9.6 Restore settings.....	35

## 1. Getting to know the phone



1、Touch screen; 2、Sensor; 3、Handset; 4、Front camera; 5、Menu key; 6、Home key7、Return key;  
8、USB Interface; 9、Headphone jack; 10、Camera; 11、SIM card socket; 12、Volume keys; 13、Power  
button; 14、Flash; 15、Microphone; 16、Speaker

※ Depending on the particular software of your phone, your phone's feature may not match those in the photo.

## **1.1 Battery**

Precautions for using the battery:

- ✧ If the battery is not being used for long periods, or the battery is exhausted, it may not boot up properly while being charged. Please give the phone time to charge, and then start to use it.
- ✧ The battery can be recharged, but as batteries are perishable goods their standby time can reduce greatly, even if properly charged. At this time please replace the battery with a new one. Using data services will consume a great amount of power and reduce the standby time.
- ✧ The battery's charge life will vary based on temperature and the many possible conditions in which you use the battery.



- ✧ When the battery is low, you will receive a notification.
- ✧ Use a standard charger to charge your phone, otherwise the battery may not charge completely.

Note: Your phone has a built-in battery , do not disassemble .

## **1.2 SIM card**

Install SIM card: the phone supports hot-swap capability, there is no need to switch off the phone.

- 1、 Insert the SIM card into the SIM card holder next to the thimble hole and press in until the SIM card holder pops up ( Figure 1 )
2. Face the metal SIM card face down, align the SIM card and the holder, and install in place (Figure 2, 3).
3. Put SIM card into the phone and install into the correct place.



## 1.3 Home Screen




Notification and Status Bar

Shortcuts



※ Press and hold a shortcut key, you can drag it to the trash or the location you want , you can also drag an icon to the shortcut location.

## 1.4 Notifications panel



Notification panel displays new messages, calendar events and ongoing activities . You can also open the Notifications panel to view reminders, event notifications, your network operator, new messages, alerts, and new events.

#### **1.4.1 Customize the Home Screen**

##### **add a gadget on the Home screen**

On the Home screen , click the menu button - > widgets , press and hold a tool , drag to the home screen, then you can release and place the icon wherever you choose.

#### **1.4.2 Move items on the Homescreen**

※ Settings menu - > Profiles - > Standard->select vibrating when touched

1. Press on the home screen until the phone vibrates, then you are ready to move any icon.
2. Continue to hold down on the button, and drag the items to your desired location. Once everything is in the right place, you can release.

#### **1.4.3 remove Items from the main screen**

1. Hold your figure down on the main screen in order to delete.
2. Drag the item to the top of the screen where the trash icon is located.
3. When the project icon turns red , release the item .

#### **1.4.4 Replace desktop wallpaper**


1. In the main screen, press the Menu key - > System Settings - > Display

2. You can set your phone wallpaper though many sources with a variety of choices:

- Wallpaper
- Dynamic Wallpaper
- Video Wallpaper
- Gallery

## **2. Call functions**

### **2.1 Voice calls and video calls**

You can make calls or video calls via dial-up applications, or by selecting a contact from the contact list. you can click on the button  to return to the main menu interface to use other functions. To return to the telephony interface , slide down the status bar and click on the current call.


※When making or receiving calls , do not touch the microphone or speakers to not affect the quality of the call.

#### **2.1.1 Voice calls and video calls through dial-up**


1. In the main screen, click  -> Open phone applications. If you do not see the dial pad screen , click

the first icon in the upper left corner to switch to the Dial tab.


2. Click on the number keys to enter the phone number.

3. Click  to make the call.

During a call, click  to add another call.


4. Click  to make video calls.


### **2.1.2 Make a call via Contacts**

1. In the main screen, click  -> Dial to open the phone application.

2. Click the upper right corner of the contacts tab to switch to the contacts tab , then click on a contact to make a call.


### **2.1.3 Make a call through the call history**

1. In the main screen, click  Open to phone application->select the call history tab.

2. Click the right button of call records  , then select a number to call.

## **2.2 Accept or reject a call**

### **2.2.1 Answer a Call**

When there is an incoming call , drag to the right to the phone icon  , then answer the phone.

### **2.2.2 End a Call**

During a call , click  to end the call.

### **2.2.3 Reject a call**

When there is an incoming call, slide left the phone icon  to refuse the call.

✖ You can also drag up to the SMS icon , so you can refuse the call but send a message to the person instead.

### **2.3 Use flight mode**


According to the law in many countries and regions, you must turn off your phone when in an aircraft. One solution is to this issue it to switch your phone to airplane mode.

1. Press down on the power button.
2. Click on flight mode.


## **3. Contact**

You can use the contacts application to store and manage information such as phone numbers and addresses . When you store contact information in your phone , you can easily contact them .


### 3.1 Copy contacts from your SIM card

1. In the contacts list , click  -> Import / Export
  2. Click to select China Mobile / China Unicom -> Next -> Phone
- \*TOOK OUT THE PERIODS


### 3.2 Create contact information

1. In the contacts list, click  .
2. In the pop-up window, select to create in a local ( including phone and SIM card ) or in the account. If you do not have an account, you need to add an Exchange account.
3. Enter contact information.
4. Click Finish to save the contact information.

### 3.3 Find contact information

1. In the contact lists, click  .
2. Enter the name of the contact you want to find, it will display the result will then display in the search bar below.

### 3.4 Edit contact information


1. In the contact list, tap the contact you want to edit and click  -> Edit.
2. Tap done to save the contact information.

### **3.5 Backup contacts via mobile phone**

#### **3.5.1 Backup contacts**



1. In the contact list screen, press  -> Import / Export
  2. In the pop-up options menu, select Export to a storage device .  
※After carrying out such operations , the pop-up window will display the storage location of what has been exported. . Vcf file.
  3. Click OK to export the contacts to the phone's U disk.
- You can back up the phone's Vcf formatted files to your computer.

#### **3.5.2 restore contacts**

1. In the contact list screen, press  -> Import / Export.
2. In the pop-up menu, select the option "import from the storage device" .  
If there are multiple . Vcf files in your phone's U disk, you can choose to restore one, several, or all of the vCards files.


### **3.6 Manage Group**

### 3.6.1 Create a group

1. In the main screen, click  -> Contacts , and then click the group tab.◦
2. Click  to create a group.
3. Enter the group name.
4. Enter the contact name , the phone will automatically associate a stored contact, click to select a contact.
5. After the operation is complete , click Finish to save the group information.

### 3.6.2 Edit Groups

You can regularly update the group contact information .

1. In the groups list , click the contact you want to edit , then click  -> Edit.
2. Enter the information you want to change , click Finish to save the changes .

### 3.6.3 Add contacts to the group

Proceed as follows to add the contact group list : When editing a group , you need to enter a contact's name , the phone will automatically associate a stored contact, then click to select a contact.




## 4. SMS

You can use the SMS application to send and receive SMS and MMS. Also, use the e-mail application to receive and send e-mail.

### 4.1 SMS and MMS

#### 4.1.1 Open the SMS program

Click  -> message , open the program.


#### 4.1.2 Create and send text messages

1. Click  , click  .
2. Click on the recipient field , enter the recipient number .

When you enter a phone number or contact name, the phone will automatically match contacts which have been listed previously. You can select from the list of contacts that you want, or continue entering new numbers of contacts.

After you select a contact or enter a number, insert a comma and then enter another contact or number.

3. Click the input field , then enter the content of the message.

4. Click  to send the text message.


### 4.1.3 Create and send MMS

Sending MMS can make your daily communication becoming more colorful . You can record audio , sing a " Happy Birthday " , or make a slide show of photos to send to your friends.



1. Click  , click  .


2. Click on the recipient field , enter the recipient number .

3. Click the input field , then start typing your message.

※If you want to enter a smiley face , you can click  , and then insert smiley.

4. The methods to convert SMS to MMS are as follows:

- Click  to add subject, enter the topic of the MMS you want to send.
- Click  to add pictures, music or video files.

5. Click  to send MMS


※When sending MMS , you can directly select the media files ( music, video or pictures ) as an attachment. Enter the file manager , press the media files you want to send , then click to add.

## 4.2 E-mail

You can use the e-mail program to send and receive e-mail messages.

#### 4.2.1 Add email accounts

You must set up your email address before you can send or receive e-mail. To use e-mail it requires a network connection.

1. Click  .
2. Enter e-mail address and password , then click Next.
3. There a multiple prompts to perform configurations, such as POP3, IMAP, Exchange.

If you do not know the mailbox configuration parameters , please consult the mail service provider, or search on the network.

4. Click Finish to complete the settings.



After adding accounts , it will enter the inbox screen by default.

#### 4.2.2 Save email attachments


1. In the Inbox screen , tap the message you want to view.
2. Click the attachment in the message to display attachments.
3. Click "Save" to download the attachment.

After being downloaded completely , it is usually stored in the download folder of the mobile phone's U disk.

#### 4.2.3 Create and send e-mail

1. In the Inbox screen, click  .
2. Click the recipient field , and enter the recipient's e-mail address.
3. Enter the message subject and message content.
4. Click  to send email

#### **4.2.4 respond to email**

1. In the Inbox screen , tap the message you want to reply to.
2. Click reply or  -> Reply to all , then you can reply to the message.

## **5. Establishing a connection**

### **5.1 Mobile Network**

Your phone has been set, and the first time you open the phone, you can access 2G/3G business of your network operator (if business is permitted) . Please be aware that you have to insert a SIM or UIM card first (some CDMA phones have cards already in them and so you do not need to insert a UIM card).

#### **5.1.1 Open data services**


1. Click->  System setting.

2. In the wireless and network section, open data services.
3. Using data services may result in additional costs, so you should deactivate the data service to avoid unnecessary costs. Clear the Enable data flow selection box to deactivate the data service.

## **5.2 Use Wireless local area network**


You can use a wireless local area network (WLAN) to access the Internet. To use WLAN on your phone, you have to be able to access the wireless access point (hotspot). Note that obstructions may cause the WLAN signal strength to weaken.

### **5.2.1 Turn on wireless local area network**

1. Click  -> System setting.
2. In the Wireless and network section, click on WLAN to turn on the WLAN.

※If you turn on the wireless local area network and data services provided by carriers at the same time, wireless local area network data service has priority, and data services provided by operators in the wireless LAN connection will continue after a break.

### **5.2.2 Connect to a wireless local area network**

1. After you turn on wireless local area network, Click  -> System settings.
2. In the wireless and networks section, click WLAN menu bar to enter the WLAN settings. Wireless local area network within the mobile search will be listed.

3. Select the network you want to connect to:


- If you selected an open network, you can connect directly to the network.
- If you select an encrypted network, you need to connect to it with the access password.


※In the WLAN Settings screen, click Add a network, and you can add a new wireless local area network.



### 5.3 Browse the Internet

You can use the browser program to access Web pages and Web-based applications.

#### 5.3.1 Browser basics

Click  , and the browser page will appear.

Click  on the screen below, and all open Web pages will be displayed, and the following operations may be carried out.

- Click on one of the switches to go into the web page.
- Click  to close the page.
- Click  to create a new page.

Press  , then open the options menu, and there is more you can do.

- **Bookmarks: click to display bookmark.**


- **Refresh: click to refresh the page.**


## **5.4 Use Bluetooth**

Your phone supports Bluetooth wireless connections. You can establish a wireless connection between the mobile phone and other compatible devices, and then make the data transfer.

You can make transfers with phone's up to 10 meters away via an established Bluetooth wireless connection. Connections may be interfered by obstacles, such as walls or other electronic devices.

### **5.4.1 Turn on Bluetooth**

1. Click  .
2. In the wireless and networks section, click on the Bluetooth switch to turn Bluetooth on, then the cell phone will display the Bluetooth icon at the top of the screen.
3. Click on the Bluetooth menu, the screen shows the device name of your phone. Click on the name column to set all of the phone's Bluetooth settings that have been detected.

If you need to modify the device name of your phone, click  -> Rename phone, Modify and click Rename.

### **5.4.2 Search for Bluetooth-enabled devices and pair with them**

Before you transfer data with other Bluetooth devices, you need to first select the devices you wish to be paired with.

1. Check your mobile phone settings, confirm that your phone is already turned on to the Bluetooth function.
2. In wireless and networks section, click on Bluetooth. The phone will automatically begin to scan for Bluetooth devices within range.
3. In search for the Bluetooth devices list, click on the device you want to pair with.

#### **5.4.3 Transfer files via Bluetooth**


You can use Bluetooth to share pictures, movies, or music with anyone you choose. To send files over Bluetooth, perform the following steps:

1. Press down on the file you want to send, then at the top a menu of options will pop up.
2. Click share, then click on Bluetooth, then select the device you want to transfer the files to.

## **6. Entertainment features**

### **6.1 Photograph and camera**


#### **6.1.1 Turn on and turn off the camera**


- Click  to turn the camera on. You can start taking pictures or recording videos.
- While viewing, click the return button to exit the camera.






### 6.1.2 Take pictures

1. Open the camera application and switch to photo mode.
2. If needed, you can adjust the camera mode. Click on the frame above the interface mode selected, and select the desired function: HDR, face beautification, panoramic pictures, multi angle pictures, automatically taking pictures of the scene, Smile shutter, best photo, exposure compensation picture. When you adjust the mode, the frame may change accordingly.





3. Keep your lens at the object to be photographed and make the adjustments.
4. Click the view interface to focus operations.
5. Click  to take photos.  
Photographs taken will be displayed in the lower right corner. You can continue to take pictures or browse photos that have been taken.

#### **6.1.3 View photos**




1. After the photo shoot, photo thumbnails are displayed in the right corner of the screen. Click on the thumbnails to view the photos.  
※When the camera is using the RAW format then there is no preview picture saved at the right corner.
2. When viewing a photo, you can do the following:
  - Click  to enter the Gallery interface.
  - Click  to share this photo with a friend via Bluetooth.
  - Click  to send this photo to a friend using their contact information.

#### **6.1.4 Shoot a video**

1. Open the camera and switch to recording mode.
2. Aim the lens to shoot objects and make adjustments.
3. Click  to start recording.

4. Click  again to stop recording.


#### **6.1.5 To view the video**

1. After shooting a video, the video thumbnail is displayed in the right corner of the screen, click on the thumbnails to view the videos.  
※A camera using the RAW format will not save a preview picture in the right corner.
2. When you view the video, you can do the following:
  - Click  to enter the Gallery interface.
  - Click  to share this video with a friend via Bluetooth.
  - Click  to send this video to a friend using their contact information.

## **6.2 Use the Gallery**

You can use Photo Gallery to manage your photos and video files.

### **6.2.1 Open gallery**

Click  to open the gallery.


### **6.2.2 View picture**

1. In the Gallery program, click on the folder that contains the image you wish to view the folder.
2. Select the desired image.

### **6.2.3 Rotate the picture**


1. When you browse a picture, click  to display the actions panel.
2. Select to rotate left or rotate right. Pictures will be saved as a new browse mode.

#### **6.2.4 Trim a picture**

1. When you browse a picture, click  to trim.
2. Use the trim tool to select the picture you want to trim.
  - Hold down on the trim tool inside, and then drag to move the clipping tool.
  - Drag the border trim tool to re-size to any amount.
  - Drag the corner of the trim tool to re-size based on a fixed percentage.
3. Click trim to trim the picture. Click Cancel to abandon your changes.

### **6.3 Enjoy the music**


#### **6.3.1 Open the music library**

Click  to display the music library.

The music program uses music related information to organize the music that you have stored in this file.

#### **6.3.2 Play music files**

1. In the music library, select a category.
2. Click on the music file you want to play.

※While playing music you can click  , and then proceed to simultaneously use other applications. To return to the music player interface, you can turn on the status bar and choose the music you are playing.

### **6.3.3 Add music to a playlist**

1. In the music library, select a category.
2. Press down on the music file, then in a pop-up menu select Add to playlist.
  - Click the now playing list, to add a song to an existing playlist.
  - Click on create a new playlist to add songs to a new playlist.

### **6.3.4 Play music list**


1. Go to the music in your library, then click on the playlist category.
2. Hold down on the playlist you want to play.
3. Click on play to start the music.

## **7. Accounts and sync**


If you are using the internet through applications that you have recently added, changes, or deleted information, this related information will be synchronized to your phone's updates.

## 7.1 Manage accounts

### 7.1.1 Add account


1. On the home screen, click  -> add account.
2. Add account.
3. Follow the on-screen instructions to add an account you will need to enter your user name and password. What information you enter is specific to the type of account you are adding.
4. Configure the account, and set which information you want to synchronize to the mobile phone. You should set the particular synchronization information with the associated type of account you want to add.
5. After setup is complete, the account interface of what you configured will appear.

### 7.1.2 Delete account

1. In the account interface, click the account you want to delete.
2. Click on the account ->  -> delete account.
3. Confirm that this account was removed.

## 7.2 Custom account synchronization information

### 7.2.1 General synchronization settings

In the account interface, Click on the account->  ->Synchronize now

In the accounts list, click the that you want to synchronize accounts.

### **7.2.2 Modify synchronization settings for account**

1. In the accounts and sync interface, click on the account that you intend to modify synchronization settings.
2. Enter data and synchronization interface, the interface will display the list of the data you can synchronize.
3. Check the data you want to synchronize to the list, and then phone will automatically sync your checked data.  
※If none of the checkboxes are automatically synchronized with the application data options, you can also click on the interface between these data and synchronize the data manually.

## **8. More applications**


### **8.1 Calendar**

You can use the calendar to manage and schedule to-DOS.


#### **8.1.1 Open the calendar**

On the home screen, click  to open calendar.

### 8.1.2 Add a new event

1. Open calendar and click , and then click on create a new activity.
2. Edit event details such as name, time, location.
3. Click finish to save the event.


### 8.1.3 Set reminders for activities

1. Within your calendar click on any activity to view its details or outline.
2. Click on the Add Reminder button to add a reminder for that activity, or click on the  to delete a reminder that has already been set.
3. Click on the time reminder in the dialogue box that appears, click on the corresponding time period option, and you can then set how long before the event you will be alerted. At the time of the reminder, the system will send you a notification about the activity.

## 8.2 Use the clock

※Click on system tools -> Clock, and the date and time will be displayed. You can use this tool to the an alarm clock.

### 8.2.1 Open clock

Click  to open the program.

### 8.2.2 Open the alarm clock program




In the clock interface, click  to open alarm clock programmed.

#### Add alarm clock

1. In the alarm list interface, click on the + to add alarm clock.

2. More information will appear to set the alarm, then enter the time and click Yes, and to complete add the alarm clock.

#### Setting the alarm

1. In the alarm list, tap the screen that displays an alarm event, click , then set the alarm interface.

2. Click on repeat, and select the desired alarm time to be repeated.


4. Click on ringtones to select a ringtone to play as alarm clock.

5. Check the vibration selection box to set the phone to vibrate when the alarm clock rings.


6. Click on the label to input alarm name.

7. Then click OK.

#### Customize alarm settings

In the alarm list interface, click  below, and then set.

## 9. Manage cell phone

Click  to set the phone in further detail.

### 9.1 Display settings

#### 9.1.1 Adjust the screen brightness

1. In the settings interface, Click to show -> light。  
※To adjust the screen brightness manually, you need to first cancel the automatic brightness adjustment check box.
2. Drag the brightness slider to the left to reduce the brightness of the screen, or drag to the right to increase the screen's brightness.
3. Click OK to save the settings.

#### 9.1.2 Setting screen standby time

You can set the screen standby time, which adjusts the delay time before the screen automatically turns off.

1. In the settings interface, click on show -> Hibernate.
2. Click on the standby time of your choice, complete and set.

## 9.2 Profile settings


### 9.2.1 Open the mute mode

1. In the settings interface, click the profile.
2. Select the mute mode selection box; except for media and alarms, all noises set will be muted.

### 9.2.2 Set the volume

You can adjust the volume while on the home screen or most all of the application screens; when you are on the phone, playing music, or playing a video, press the volume keys to adjust the volume.


You can use the following methods to adjust the volume.

1. In the settings interface, Click on story mode -> Standard ->  .
2. Drag the volume slider to the left to decrease the volume, or drag to the right to increase the



volume.

3. Click OK to save the settings.

### 9.2.3 Change ringtones

1. In the settings interface, Click on story mode -> Standard ->  ->Voice call ringtone
2. Select the ringtones you want, when selected the ringtone will play.
3. Then click OK.

### 9.2.4 Setting text message ringtones

1. In the home screen, click  .
2. In the messages list, click  ->settings-> Message notification settings -> Ringtones

3. Click on the ringtone you want to use, then the selected ringtone will play.

### **9.3 Set the text to speech**

Use the text to speech settings, you can configure the Android text to speech synthesizer so that the application can use this feature.

#### **9.3.1 Adjust voice speed**

1. On the settings screen, click on the languages and input methods -> Text to speech **(TTS)**output -> Speed.
2. Set the writing speed.

### **9.4 Security settings**

#### **9.4.1 Open PIN code of the SIM card**

1. In the settings interface, click on the safe -> Set up SIM card lock
2. Tick the box lock SIM card.
3. Use the keyboard to print the PIN code of your SIM card, and then click OK.
4. If you change the SIM card PIN code at any time, tap change PIN code of your SIM card.

※At any time you can use the mobile phone for emergency calls.

#### **9.4.2 Enable screen lock pattern protection**

You can set the screen lock pattern for when the screen is locked. It is required to draw the screen unlock pattern properly to unlock the screen.

1. In the settings interface, click on the safe -> Screen lock -> Pattern
2. Follow the on-screen instructions to draw the unlock pattern.
3. Click on continue.
4. Draw the unlock pattern, and click OK.

#### **9.4.3 Using digital PIN code to protect your mobile phone**

You can set a digital PIN code to lock your cell phone.


1. You can set a digital PIN code to lock your cell phone. -> Screen lock -> **PIN**
2. Enter at least four digits.
3. Click on continue.
4. Enter the same numbers again and then click OK.

To change the PIN code, click on the safe -> Screen lock -> **PIN**

## **9.5 Management applications**

### **9.5.1 View installed applications**

1. In the settings interface, click on the application.
2. You can do the following:

- Click  and click to sort by size, and then click an application to view details.
- Click an application to view details.

### **9.5.2 Uninstall application**

※The applications that the system come with cannot be uninstalled.

1. In the settings interface, click on the application.
2. Click on the application you want to uninstall, click Uninstall, and follow the on-screen prompts to complete the uninstall.

## **9.6 Restore settings**

### **9.6.1 Restore factory settings**

Restoring factory setting will delete your personal data stored on the mobile phone, including e-mail accounts, system settings, application settings, and applications that you have installed; the system level updates will however not be deleted. The setup contains a check box, and if you check it then all the data stored in the mobile phone from a USB memory stick will be deleted; this data may include your downloaded or backed up music or photos.

1. In the settings interface, click on backup and reset -> Restore factory settings.
2. The mobile phone will start to restore factory settings, and will automatically reboot.

**Infinix**