

SETUP GUIDE

Interface



IMPORTANT INFORMATION - PLEASE READ BEFORE SETTING UP YOUR KURIO

- The Kurio phone must be set up by an adult to ensure an appropriate level of protection for the users of the device.
- To turn off your Kurio phone correctly, press the Power button until the pop up message appears onscreen, and then select "Power off". Avoid switching off the device by pressing and holding the Power button until the unit stops.
- Do not fully discharge the battery (keep at 5% or more). Recharge it to full power regularly to preserve the battery.
- Please connect your Kurio phone to Wi-Fi frequently to receive and enjoy the latest upgrades. Updates are pushed to your handheld wirelessly.
- If you encounter any issue with your device, please do not return it to the store. Please review our FAQs & troubleshooting info or contact our tech support team for help at www.kurioworld.com/support or through the Customer Care/Kurio Support apps on the phone.

Find more tips and information at WWW.KURIOWORLD.COM

Installation



Install the SIM Card

Delicately remove the back cover of the phone and remove the battery. Carefully slide the SIM card into the SIM card socket until the card clicks into place.

Make sure that the card's gold contacts face into the device and that the upper-left angled corner of the card is positioned as shown.

Installing the Battery

Slide the battery into the compartment so that the tabs on the end align with the slots at the bottom of the phone, making sure the connectors align.

Gently press down to secure the battery.



Micro SD card slot



Micro USB/Charger

- Charge the phone for 3h before 1st use.
- Press the Power button to start.
- After first start up, the phone may ask for the PIN code of the SIM card .

Important Recommendation!

Choose an appropriate plan for your phone

KurioGenius is compatible with all mobile operators and plans but we strongly recommend a plan with unlimited SMS/text and a data/internet plan with at least 200 MB/month minimum.

The phone system needs to send SMS/texts and synch with our services to work at its full capacity.

Disclaimer

Please note that the Kurio Phone should not be regarded as a substitute for the personal care and supervision of any person using the product. Due to the nature of wireless communications, transmission and reception of data can never be guaranteed. Data may be delayed, corrupted (or be totally lost). Although significant delays or losses of data are rare, when wireless products such as the Kurio Phone are used in a normal manner with a well-constructed network, Inspiration Works accepts no responsibility for damages of any kind resulting from delays or errors in data transmitted or received using its products or for failure of its products to transmit or received such data.


The recipient of the documentation shall endorse all risks arising from its use. In no event shall Inspiration Works be liable for any incidental, direct, indirect consequential or punitive damages arising from the use or inadequacy of the documentation, even if Inspiration Works has been advised of the possibility of such damages and to the extent permitted by law.

Information in this document is subject to change without notice. Inspiration Works reserves the right to change or improve its products and to make changes in the content without obligation to notify any person or organization of such changes or improvements.

Visit the Kurioworld.com website for current and supplemental information concerning the use and operation of this product

Installation

1- Select a language





Tap on the default language to open a list of all available languages. Select your language from the list and tap Start to continue.

2 - Select a Wi-Fi Network

If you find yourself within range of a wireless network, you can now make the connection. Simply select your network from the list and enter the password if required. Then tap on Connect.

A data connection (Wifi or 3G) is required to setup the device.



3 - Select Your Time Zone



When your Android device is connected to a cellular or Wi-Fi network, it automatically updates its clock to correspond to your current time zone. If you're unable to connect to a network (for example, when you're on an airplane) use the Time Settings to manually change the time zone on the device.

Kurio Genius Configuration

4- Log In or Sign Up

If you already have an account, enter your credentials.

If you do not have an account, select "Sign-Up" to create a new account.



5 - Create a Kurio Genius Account

Follow all of the steps during the setup, enter the Parental e-mail and Password.

A confirmation code will be sent to your e-mail address to confirm its accuracy. **Please make sure that you can have access to your e-mail during the process.**

6 - Confirm Your Account

Enter the confirmation code sent to you by e-mail.


Then press OK to move to the next step.



7 - Activate Device Administrator

If the Child mode is activated on the phone, the Android system will ask you to allow the Kurio Genius application to obtain administrative rights to the phone's system.


Press Activate to ensure the Kurio Genius parental controls cannot be deactivated.



Kurio Genius Configuration

8 - Complete the information

Fill the information to create a new child account. Each child account will be linked to your parental account.




9 - Activate GPS and Data Access

In order to utilize all of the features of the Kurio Genius system, GPS and Data access must be activated on your child's phone. Follow instructions to activate these options.

10 - Settings

The phone is now set up! On this last screen, you will have access to all Kurio Genius options and settings to configure properly your child's phone. Navigate through this menu to access all settings.

NOTE: Some configuration parameters have to be set from the Kurio Phone website on this address: kuriophone.com. For a more convenient experience we recommend managing the Kurio Phone settings through the Kurio Phone website.



11 - Using the Kurio Genius

Your child can see the active settings and usage limits you have set by accessing the Kurio Genius app. Parents can access the settings using the settings icon on the top right. Parents can log in using their email and password or define a parent PIN access on the website for convenience.



Kurio PHONE

The Ultimate Smartphone for Children!

Tech Support & Warranty Information

- If you have any questions setting up or using your Mobile Phone, please visit www.kurioworld.com to find out more about Kurio, read our related FAQs, and for any technical support. All of our products have a 1 Year Limited Warranty. In the unlikely event you experience any problems with your Kurio, please visit www.kurioworld.com/support/ to contact Kurio Customer Service. If the service representative is unable to solve the issue, he or she will provide instructions regarding how to have your Kurio serviced if it is under warranty.
- Please note that this handheld is warranted only to the original purchaser for a period of twelve months from the original purchase date, under normal use and service, against defective workmanship and materials. Please still contact Kurio Customer Service for repair & replacement options, especially for a broken screen or other spare parts.
 - Please visit www.kurioworld.com for the full details of Kurio's 1 Year Warranty.

Recycling



Waste electrical products and batteries should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority for recycling advice.

CAUTION – ELECTRICALLY OPERATED PRODUCT – As with all electric products, precautions should be observed during handling and use to prevent electric shock. Adult supervision is recommended.

Please retain this manual for further reference.

Copyrights

© 2012 BBIGG APPLICATIONS INC © 2009-2014 KIDSEMAIL COPYRIGHT © 2013 KINGSOFT SOFTWARE. ALL RIGHTS RESERVED. COPYRIGHT © 2013 FARLEX, INC © GREENLIFE APPS WINX CLUB ROCKS THE WORLD © BUDGE STUDIOS INC. 2014. WINX CLUB™ WINX CLUB IS A TRADEMARK OF RAINBOW SRL. USED UNDER LICENCE BY BUDGE STUDIOS INC. © 2014 GAMELOFT. ALL RIGHTS RESERVED © 2013 SYBO AND KILOO. ALL RIGHTS RESERVED. © MAGMA MOBILE. ALL RIGHT RESERVED © MOBIGAME 2012-2014 ZEPTOLAB, CUT THE ROPE 2 AND PUDDING MONSTERS ARE THE TRADEMARKS OR REGISTERED TRADEMARKS OF ZEPTOLAB UK LIMITED. © 2010-2014. ALL RIGHTS RESERVED. © 2014 APPLIFT COPYRIGHT © 2010, 2012, 2013, 2014 HALFBRICK STUDIOS. HALFBRICK STUDIO AND ITS LOGO ARE TRADEMARKS OF HALFBRICK STUDIOS PTY LTD © 2008-2014 SPOTIFY LTD. © PLAY7 LTD. 2014 COPYRIGHT © 2014 MAGIKFLIX INC. "THE BLUETOOTH® WORD MARK AND LOGOS ARE REGISTERED TRADEMARKS OWNED BY BLUETOOTH SIG. INC. AND ANY USE OF SUCH MARKS BY CIDE INTERACTIVE IS UNDER LICENCE. OTHER TRADEMARKS AND TRADE NAMES ARE THOSE OF THEIR RESPECTIVE OWNERS." CRONLAB® IS A CRONLAB LIMITED REGISTERED TRADEMARK ANDROID, GOOGLE PLAY AND OTHER MARKS ARE TRADEMARKS OF GOOGLE INC. THE ANDROID ROBOT IS REPRODUCED OR MODIFIED FROM WORK CREATED AND SHARED BY GOOGLE AND USED ACCORDING TO TERMS DESCRIBED IN THE CREATIVE COMMONS 3.0 ATTRIBUTION LICENSE. ICHAPER™ – THE MOBILE CHAPERON™ ©COPYRIGHT 2012-2014, REGISTERED TRADEMARKS OF INNOVATION 31 SAS MICROSDHC LOGO IS A TRADEMARK OF SD-3C, LLC.

For more information about Kurio, please go to www.kurioworld.com.



Made in China
Printed in China
July 2014
V00

Exposure to Radio Frequency Energy

FCC Part 15 Information to User

Pursuant to part 15.21 of the FCC Rules, you are cautioned that changes or modifications not expressly approved by KD INTERACTIVE could void your authority to operate the device.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Restricted Use of Electronic Devices

- The use of electronic/electric devices may interfere with safe operation of some aircraft and can be restricted with some airline companies. Please check with your airline company before travelling.
- Kurio Phone has an Airplane Mode. Please go into the Settings of the Android Interface to switch Kurio Phone into Airplane Mode. All wireless connections will be turned off.

Children and phones

The scientific evidence does not show a danger to any users of phones from RF exposure, including children and teenagers. The steps adults can take to reduce RF exposure apply to children and teenagers as well:

Reduce the amount of time spent on the mobile phone

This device is in compliance with Specific Absorption Rate (SAR) for general population / uncontrolled exposure limits (1.6 W/Kg) specified in FCC CFR part 2 (2.1093) and ANSI/IEEE C95.1-2005 and had been tested in accordance with the measurement methods and procedures specified in IEEE 1528-2003.

Battery Use and Safety

IMPORTANT: Handle and store batteries properly to avoid injury or damage. Please check regularly the condition of the battery. Should the case be damaged or showing evidences of corrosion or exposure to liquid, remove the battery from the device and replace it by a new one.

DO NOT disassemble, crush, puncture, shred or otherwise attempt to change the form of your battery. Do not put a high degree of pressure on the battery. This can cause leakage or an internal short-circuit, resulting in overheating.

DO NOT let the phone or battery come in contact with liquids. Liquids can get into the phone's circuits, leading to corrosion. If the phone or battery get wet, have them checked by the customer support.

DO NOT place your battery in or near a heat source. Excessive heating can damage the phone or the battery and could cause the phone or the battery to explode. Do not dry a wet or damp battery with an appliance or heat source such as a microwave oven, hair dryer, iron or radiator. Avoid leaving your phone in a car in high temperatures.

DO NOT dispose of the phone or the battery in a fire. The phone or battery may explode when overheated.

DO NOT handle a damaged or leaking battery. Do not let leaking battery fluid come in contact with your eyes, skin or clothing. For safe disposal options, contact support.

Avoid dropping the mobile phone. Dropping the phone or the battery, especially on hard surface, can potentially cause damage to the phone and battery.

NEVER use any charger or battery that is damaged in any way.

DO NOT allow the battery to touch metal objects. Accidental

short-circuiting can occur when a metallic object (coin, key, Jewellery, clip or pen) causes a direct connection between the + and - terminals of the battery. This may damage the battery or the object.

IMPORTANT: Use only batteries specifically designed for your device and charge the batteries with approved chargers only.

- Do not damage or deform the power supply USB cable. If it is damaged or deformed, it may cause electric shock or malfunction when used. When removing from wall outlet, be sure to remove by holding the plug attachment and not by pulling the cable.
- The power adapter & cable should be plugged in near the unit, so it is easily accessible and does not strain the cable.
- While using some applications that use a lot of the device's processing capacity, the device may become warm. If this occurs, take a short break from using the device to let it cool down.
- Keep the unit clean by wiping it with a slightly damp cloth.
- All packing materials such as internal bags, plastic collars, plastic films, screen protector film, and carton inserts are not part of this product and should be removed before handing the device over to a child. Please keep the box and this guide for further reference.
- Do not try to disassemble the unit.
- Avoid using the Kurio Phone while charging: this may alter the battery charging process and the battery life of the device. Keep the unit out of direct sunlight and away from any direct heat source.
- Do not expose the unit to moisture or water.
- To prevent hearing damage, never use earphones at excessive volume levels. Listening to loud sounds for an extended period may cause temporary or permanent hearing loss.
- Never use Kurio Phone while operating a motor vehicle or bicycle.
- If you feel discomfort in your hands or any pain using Kurio Phone, please stop immediately.
- In case of long period of use, take frequent breaks.
- If a small part is coming out of the Kurio Phone, don't try to remove it. Keep it away from small children.
- Never force a connector into a port of Kurio Phone. If a connector and a port do not join with reasonable force, make sure that the connector matches the port and that you have positioned the connector correctly in relation to the port.
- To clean up the screen, simply use a soft damp cloth. Do not use alcohol, solvent, aerosol spray or abrasive cleaners to clean your Kurio Phone.
- The product and the adapter should be periodically examined for conditions that may result in the risk of fire, electric shock, or injury to people and that, in an event of such conditions, the adapter should not be used until properly repaired.