

MPMAN PH360
ANDROID SMARTPHONE

INTRODUCTION

Thank you for choosing PH360, Dual SIM Android smart phone. This smartphone is running on Android OS, v4.2.2 Please read this guide carefully and keep it for future reference.

Pictures used for function demonstration may look different from reality

Table of Contents

1	Safety	4
1.1	Safety Precautions	4
1.2	Using your phone safely	5
2	Understanding your Phone	9
2.1	Your Phone	9
2.2	Description Icons	10
2.3	Inserting & Removing the battery	11
2.4	Charging the battery	12
2.5	Power ON/OFF	13
2.6	Enter main menu	13
2.7	Enter sub menu.....	14
2.8	Use notification panel	14
2.9	Expand main interface	14
2.10	Add icons on the main interface.....	14
2.11	Move icons on the main interface	15
2.12	Delete icons on the main interface.....	15
2.13	Change wallpapers	15
2.14	Install APK through file manager	16
3	Using your Phone	17
3.1	Main Menu & Its Functions	17
4	Maintenance	20
5	Taking Care of your Device	20

Safety

■ 1.1 Safety Precautions



Please read through the following briefings carefully, and act in accordance with these rules, so as to prevent causing any danger or violating any law.

- Your mobile phone has been designed to comply with applicable safety requirements for exposure to radio waves. The radio wave exposure guidelines employ a unit of measurement called Specific Absorption Rate(SAR). The recommended SAR limit for mobile handset is 1.6 W/Kg averaged over a 6 minutes period and taken over a volume containing a mass 1g of human tissue.
- The highest SAR value for this mobile phone model is 0.663w/kg averaged over a 6 minutes period and taken over a volume containing a mass 1g of human tissue.
- Use cell phone when the signal strength is good. Keep your calls short or instead use headset or send a text message . This advice applies especially to children, adolescents and pregnant women.
- If you are using a Bluetooth headset device , please make sure it has a low power emitter.

■ 1.2 Using your phone safely



On The Road

Using a phone while driving is illegal in many countries. Please follow local laws and drive safely at all times.



Near Sensitive Electronics

Don't use your phone near sensitive electronic equipment – particularly medical devices such as pacemakers – as it could cause them to malfunction. It can also interfere with the operation of fire detectors and other automatic-control equipment.

For more information about how your phone affects pacemakers or other electronic equipment, please contact the manufacturer or your local distributor.

Your phone may cause interference when used near TVs, radios or automated office equipment.



While Flying

Your phone can cause interference with aircraft equipment. So it's essential you follow airline regulations. And if airline personnel ask you to switch off your phone, or disable its wireless functions, please do as they say.



In Hospital

Your phone may interfere with the normal operation of medical equipment. Follow all hospital regulations and turn it off when you're asked to by posted warnings or medical staff.



At a Petrol Station

Don't use your phone at petrol stations. In fact, it's always best to switch off whenever you're near fuels, chemicals or explosives.



Around Water

Keep your phone away from water (or any other liquid). It's not a waterproof model.



Making Repairs

Never take your phone apart. Please leave that to the professionals. Unauthorised repairs could break the terms of your warranty.



Broken Antenna

Don't use your phone if the antenna is damaged, as it could cause injury.



Around Children

Keep your mobile out of children's reach. It should never be used as a toy and it might not be good for their health.



Original Accessories

Only use the original accessories supplied with your phone or those approved by the manufacturer. Using unapproved accessories may affect performance, make the warranty void, break national regulations on the use of mobile phones, or even cause injury.



Near Explosives

Turn off your phone in or near areas where explosive materials are used. Always obey local laws and turn off your phone when requested.



Emergency Calls

To make an emergency call your phone must be turned on and in an area where there's network coverage. Dial the national emergency number and press 'send'. Explain exactly where you are and don't hang up until help has arrived.



Working Temperature


The working temperature for the phone is between 0 Degree and 40 Degree Celcius. Please don't use the phone outside the range. Using the phone under too high or too low temperature might cause problems.



At very high volume, prolonged listening to a mobile phone can damage your hearing.

2 Understanding your Phone

2.1 Your Phone





■ 2.3 Inserting & Removing the battery

Inserting the battery

1. Open the battery cover on the back of your phone.
2. Align the battery's contact points with those of the phone and gently press the battery down into place.
3. Replace the battery cover clicking it back into position.

Removing the battery

1. Switch off your phone.
2. Open the battery cover.
3. Lift the battery up and out of your phone.

■ 2.4 Charging the battery

The rechargeable Li-ion battery that comes with your phone is ready to be used, but is not charged. It is easy to do & can be done in 3 simple steps below:

1. Connect the charger to your phone, and plug it into a socket.
2. The battery indicator in the corner of the screen will scroll to show you it's charging.
3. When fully charged, the battery indicator will stop scrolling.
4. Disconnect the charger from your mobile, and unplug.

■ 2.5 Power ON/OFF

Long Press the power key to power-ON/OFF the phone. When you turn your phone on, it'll automatically check the SIM and show the following information on screen:

- **Input phone lock code:** If you've set a lock code.
- **Input SIM1 PIN:** If you've set a PIN for your SIM1.
- **Input SIM2 PIN:** If you've set a PIN for your SIM2.

Note:

The PIN is supplied with your SIM. Please replace it with your own PIN code as soon as possible. Enter the wrong PIN three times, and your SIM will be locked. Then you'll need to contact your network service provider to ask for a PUK code to unlock it. It is applicable for both the SIMs if you are using 2 SIM Cards.

■ 2.6 Enter main menu

In idle mode, press the Menu key to enter the main menu on the desktop and click the Home key to return.

■ 2.7 Enter sub menu

Once at the main menu, click the icon to select the submenu, press Back Key to return to the previous menu, and press the Home Screen to return to the home screen.

■ 2.8 Use notification panel

As a new notification appears in the notification area, slide down in the area to view the contents of the notification.

■ 2.9 Expand main interface

The main interface may extend and exceed the screen width to provide more space for newly added shortcuts and tools. Slide your finger horizontally on the main interface to extend to the left or right area of the main interface.

■ 2.10 Add icons on the main interface


Long press any empty space on the main interface to open "Add to Home screen". Select "Shortcuts", "Widgets", "Folders", etc to add.

You can also long press the icon on the main menu until it's enlarged and the mobile phone vibrates, and copies the icons in the main menu to the main interface.

▪ 2.11 Move icons on the main interface

1. Long press the icon on the main interface until it's enlarged and the mobile phone vibrates.
2. Drag the icon to the desired position and then release it.

▪ 2.12 Delete icons on the main interface

1. Long press the icon on the main interface until it's enlarged and the mobile phone vibrates.
2. Drag the icon into  to delete it.

▪ 2.13 Change wallpapers

1. Long press "Touch screen" to open the menu.
2. Press "Wallpapers" "Gallery /Live wallpapers / "Wallpapers", and Select the wallpaper and press "Set wallpaper" to complete.

■ 2.14 Install APK through file manager

PK is a packaging file format for the Android mobile operating system.

1. Please copy the downloaded APK file into the SD card, and then insert the SD card into the terminal.
2. In idle mode, click Main Menu to enter the main menu.
3. Click “File Manager” to enter the directory of SD card.
4. Click the APK file you wish to install, and follow the installation wizard.

■ 3 Using your Phone

■ 3.1 Main Menu & Its Functions

Select  to enter the main menu...

Allows you to view a list of features available in your phone-

1. Alarm

Allows you to set the alarm from Clock.

2. Browser

Browse the search engine- default set as Google.

3. Calculator

Allows you to make tedious calculations quickly.

4. Calendar

View the calendar.

5. Camera

Allows you to click pictures anytime you want.

Your PH360 has 2.0 Mega Pixel Camera which ensures you click good quality of pictures and stores them under the Gallery folder. In Camera, easily slide to Camcorder to record Video Files.

Note: You need to have SD card to store the Pictures & Videos.

6. Contacts

Contacts from your SIM can be downloaded into your phone by Import / Export

Go to: Menu>contacts>Press Menu Display>Import/Export

7. Email

Allows you set up your POP/IMAP email accounts.

8. Gallery

Allows you to save & view photos & videos.

9. Messaging

Allows you to view messages sent & received as a thread.

10. Music

View the list of songs available in your phone.

View the artists, albums, playlists & more.

11. File Manager

You could install the files in APK format.

12. Settings

Modify settings under the following-

- SIM management
- Wi-Fi
- Bluetooth
- Data usage
- Audio profile
- Display
- Storage
- Battery
- Apps
- Locations access
- Security
- Language & input
- Backup & reset
- Add account
- Date & time
- Scheduled power on & off
- Accessibility
- Developer options
- About phone

13. SIM Toolkit

This service is provided by the operator.

It provides many types of personalized message services.

14. Sound Recorder

Records sound.

■ 4 Maintenance

Use a dry soft cloth to wipe general dirt.

Do not use a hard cloth, benzene or thinner to wipe the phone, otherwise, the surface of the phone will be scratched or could even result in the fading of colour.

■ 5 Taking Care of your Device

Your device is a product of superior design and craftsmanship and should be handled with care. The following suggestions will help you protect your phone:

- Always keep the small parts of the phone away from children.

- Keep the device dry . Precipitation, humidity, and all types of liquids or moisture can contain minerals that will rust electronic circuits. If your device does get wet, remove the battery , and allow the device to dry completely before replacing it.
- Do not use or store the device in dusty , dirty areas. Its moving parts and electronic components can be damaged.
- Do not store the device in high or cold temperature. High temperatures can shorten the life of electronic devices and damage batteries.
- Do not attempt to open the device other than as instructed in this guide.
- Do not drop , knock , or shake the device . Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals , cleaning solvents , or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.
- Do not paint the device. Paint can clog the moving parts and prevent proper operation.
- Use chargers indoors.

For more information please check our website

www.mpmaneuropa.com