



SOAP

evo

User Manual

Summary

Before using Your phone	5
Guidelines	5
Mobile Phone profile	6
Frontal view	6
Lateral and inferior view.....	7
Getting started.....	8
Installing the battery	8
Installing the SIM card	9
SIM cards installation scheme	9
Installing the Memory card	10
Memory card installation scheme	10
Charging the battery.....	10
Notices on using the battery	11
PIN Code	11
General Instructions.....	11
Call key.....	11
Power on/off	11
Virtual Standard keypad	12
Screen lock.....	12
Languages and input language	13
Incoming call alert	13
Services.....	13
Caller groups.....	13
Stand-by screen	14
Basic operations.....	14
Power on	14
Power off	15
Dial a call.....	15
Adjust receiver volume.....	15
Answer a call.....	16
Options for phone conversations	16
DTMF tones	16
SMS Reading	16
Missed calls.....	16
Answering machine	16

Main menu.....	17
Phonebook	18
Messages	19
Inbox.....	20
Drafts.....	20
Outgoing.....	20
JunkBox	20
Delete messages	20
Broadcast messages	21
Call logs.....	21
Dialer	22
NGM – Special Functions.....	23
Calls & SMS firewall.....	23
Phone control.....	23
Privacy firewall	25
Answering machine.....	25
Background sound.....	26
Wi-Fi	26
Bluetooth.....	26
Settings	27
User profiles	27
Phone settings.....	28
Dual SIM settings.....	28
Touch calibration.....	29
Network settings	29
Security settings	29
Call settings	29
Restore factory settings	30
Connectivity	30
Camera	31
Image	33
Opera	34
Services.....	34
SIM Services	34
WAP (Internet service)	34
Licence manager	35
Nimbuzz.....	35

Maps.....	35
Java.....	35
Calendar.....	35
File manager.....	36
Alarm.....	36
Media player.....	37
Sound recorder.....	37
FM Radio.....	37
E-mail.....	38
Tasks.....	38
Notes.....	38
eBook Reader.....	38
Calculator.....	39
Giochi.....	39
Coffer function.....	40
Coffer Phonebook.....	40
Coffer messages.....	40
Coffer Call log.....	41
Change Coffer Lock.....	41
<i>Block incoming calls</i>	41
<i>Password reminder</i>	41
T9 Text input.....	41
USB connection.....	42
Maintenance and Safety.....	42
Charger and adapter.....	42
Battery Information and Care.....	42
General Notice.....	42
Troubleshooting.....	43
Abbreviations.....	44
Certifications.....	45

Before using Your phone

Introduction

Thank You for choosing the GSM/GPRS/EDGE **NGM SOAP Evo** mobile phone.

To make sure that your phone is preserved in optimal conditions, please read carefully the present user manual and keep it at hand for future references. The information in this manual is believed to be correct at the time of printing; NGM reserves the right, however, to change or modify any of the specifications without notice. The images in the present manual have the sole function of illustrating the telephone functions, it is possible that they slightly differ from Your telephone and what is shown on it, depending on the installed software, SIM card and Your service provider.

Guidelines

For your safety and proper use of the mobile phone, please read the following guidelines carefully:

Do not switch on the mobile phone when close to a chemical factory, gas station or other explosive objects.

- When driving, please use the headset for safety; unless in emergency, always stop the car on the roadside to have a call conversation without the headset.
- Since the use of the mobile phone can cause interference in the aircraft, never use the mobile phone on an airplane. The use of the mobile phone on aircrafts is dangerous and illegal; switch off the mobile phone before boarding.
- Pay special attention to the use of the mobile phone near heart pacemakers, deaf-aids and other medical equipments, because the mobile phone can cause interference with them.
- The use of non-original factory's accessories and parts will lead to the loss of guarantee.
- Do not dismantle the mobile phone without permission. In case of failure, please contact the supplier as soon as possible.
- Do not plug the charger into the mobile phone and charge without battery. Always power off the mobile phone when taking out the battery; otherwise the telephone memory may be damaged.
- When charging the mobile phone, always keep it in the place with good ventilation, on a heat sink and away from flammable and explosive objects.
- In order to avoid demagnetization, always keep the mobile phone away from magnetic objects such as CDs, credit cards etc.
- Ensure the mobile phone does not contact any liquid; if such happens, remove the battery and contact the supplier immediately.
- Do not use the mobile phone in an environment at too high or too low temperature, never expose the mobile phone to strong sunshine or too moist environment. The suitable temperature for the phone and accessories is between 0°C and 40°C. The height to use the phone shall be less than 2,000m.
- Do not use liquid or wet cloths with strong detergents to clean the mobile phone.
- This mobile phone has picture capturing functions, which shall be used following the related laws and regulations.
- Always keep the mobile phone out of children's reach. Do not throw or vibrate the mobile phone because violent treatment to the mobile phone may damage the inner circuits and precise structures.
- Please do not discard the waste battery into general household garbage. Please deal with the waste battery according to provisions where they are definitely made.

Warning: NGM Italia will not be bear any responsibility for any incompliance with the above guidelines or improper use of the mobile phone. Our company keeps the right to modify any of the content in this user guide without public announcement in advance. The content of this manual may vary from the actual content displayed in the mobile phone. In such case, the latter shall govern.

Mobile Phone profile

The mobile phone is equipped with a resistive touch screen (sensible to pressure), a vibration motor, a charger/data common transmission port.

In the pictures below you can find the front and the back views of the phone.

Frontal view



Lateral and inferior view




Getting started

Installing the battery

The mobile phone is suitable only for original NGM battery and accessories. If the telephone is not going to be used for some time, it is recommended to put battery and telephone separately back into the original packaging. Open the back cover, applying pressure to the tiny slit on the back side of the phone. Place the battery into the correct position by aligning its contacts with the ones in the phone. In order to place the cover back, fit it on the back of the phone and press gently along all its sides until the cover clicks into position.

Note: install the battery following the above scheme in order to avoid possible damage to the battery contact patch.



Installing the SIM card

You can apply for two different phone numbers, two different mobile phone network service providers and thus obtain two SIM (Subscriber Identification Module) cards.

With these two SIM cards, you can use all the functions of your mobile phone. The SIM cards save the parameters needed for communications and personal data, including PIN (Personal Identification Number) code, phonebook, short message (SMS) and other system services.


Warning: do not distort or scratch the SIM card nor let it contact static electricity, dust or moisture. If it is lost, please contact immediately your network operator for help.

Before SIM card installation, please switch off the mobile phone. The SIM cards have to be inserted into the slots placed in the back side of the phone, under the battery. To remove the cover, start from the slit on the lower back side of the phone. Both SIM cards must be inserted with the golden contacts facing downwards.

Note: if only the SIM1 slot contains a SIM card, then only the primary SIM slot will function; likely, if only the SIM2 slot contains a SIM card, only the secondary slot works. When two SIM cards are inserted into both slots, you can freely choose the work mode you wish.

Note: as the SIM card is a small object, keep it out of children's reach to prevent children from swallowing it!

SIM cards installation scheme




Installing the Memory card

Since the mobile phone does not have enough storage space, in order to use some functions which need more memory, you will need to install a **memory card** (this mobile phone use **T-FLASH card**). The MicroSD card must be inserted into the back side of the phone, after removing the back cover. A dedicated slot for the memory card is placed beside the SIM cards slots (see below); unlock the memory card slot by pushing the metal harness toward the "**Unlock**" position, then insert the microSD card with the golden contacts facing downwards. Then close and lock the harness.

Note: as the T-Flash card is a small object, keep it out of children's reach to prevent children from swallowing it!

Memory card installation scheme



Charging the battery

The new battery will reach the optimal efficiency when it has undergone several continuous complete charges and discharges. When the battery is low, charge it in time. Over-discharge can damage the battery.

Connect the charger to the AC power supply and to the phone USB connector, at the bottom of the phone. During charging, the battery capacity icon on the screen will report the charging process. After the battery is full, the battery icon will be full. Cut the connection of the charger with the AC power supply and then the connection of the charger with the mobile phone.

Note: use only the provided USB cable for recharging the device. Charge the battery indoors in a dry and favourable environment. It's normal for the battery to get slightly warm during the charging process.

Warning: use only original accessories to charge the battery. The use of other accessories may damage your mobile phone and cause risks!



Notices on using the battery

The performance of the battery is affected by many factors, including radio barrier network settings, signal strength, signal strength, work temperature, chosen and used functions or settings as well as phone accessories, tones, data or other applications.

For optimal performances, please follow the rules below:

- New battery or the battery having been idle for long need charging for long. The standard voltage scope for the battery is 3.6V-4.2V.
- During charging, keep the battery at room temperature or similar temperature.
- With time passing by, the battery will gradually be worn and thus need longer time to charge. This is normal. However, after normal charging, if call duration decreases but charging time increases, you need to buy another battery from the original manufacturer or authorized by the original manufacturer. The battery of inferior quality can damage your mobile phone and cause danger!
- If the phone is overused at low battery when charging, there might need a longer time for the charge indicator to be shown on the screen.

Note: please dispose the battery according to the local regulations. Try to recycle the battery as possible. Do not treat the waste battery as common waste.

Warning: do not throw the battery into fire so as to prevent fire hazard. The broken battery may cause explosion.

Warning

Charging the mobile phone by improper means can cause to explosion. Always refer to the related regulations for the disposal of the battery.

PIN Code

PIN1 Code: it is the personal identification number used to enter SIM and able to prevent others using SIM1 without permission. If the mobile phone has activated the PIN1 code protection, when the mobile phone is switched on, the screen will display "Input PIN". In the process of inputting PIN1 code, the screen will use "*" to represent the input content. While obtaining SIM, you can obtain its PIN1 code.

PIN2 Code: it is the personal identification number used for some special functions.

PUK Code and PUK2 Code (8 digits): to change the locked PIN code, you need to use PUK (Personal Unblocking Key) code. To change the locked PIN2 code, you need to use PUK2 code. If these two codes are not provided together with the SIM cards, ask the local service provider for them.

Warning: if you input the wrong PIN code for three times continuously, the SIM card will be locked. Please contact the network operator immediately for help. Attempt to unlock the code may make the SIM card ineffective forever!

General Instructions

Call key


In idle mode, press the call key to display a list of recent calls; SIM1 and SIM2 support, respectively, 20 voices including incoming calls, missed calls and dialed calls. Select a contact list and press again SIM1 or SIM2 key to call the number.

Power on/off

In call mode, use this key to end a call; otherwise, use it to leave the current menu and go back to the standby screen. Press and hold this key for 4~5 seconds to power on or off your phone.


Virtual Standard keypad

The phone has a virtual standard keypad, that can be opened from the Stand-By screen with the "Virtual Keypad" Icon. Use these keys to input numbers, passwords, letters and symbols when writing messages, or to choose menu options. Pressing "#" for a few seconds will activate/deactivate quickly the vibration mode from the stand-by screen.



Screen lock

If you want to lock the screen, press and hold **OK/Main** key from the main screen. To unlock, drag the bubble over the thumb snacks to "release Soap".



Languages and input language

Italian is the default phone language and default text-input language. For different areas, there are 4 languages available (English, French, Spanish, German) with the corresponding input modes.

How to change the menu language: from the main menu select **Settings > Phone settings > Language > [select a language]**.

How to change the input language: from the main menu select **Settings > Phone settings > Preferred writing language > [select a language]**.

Incoming call alert

The mobile phone has an inbuilt vibration motor and a buzzer, and provides several incoming call modes:

- **ring only**
- **vibrate only**
- **vibrate and ring**
- **vibrate and then ring**

To modify the call alert, select: **Settings > User profiles > [selected profile] > Options > Customize > SIM1/SIM2 Alert type**.

To quickly enable **Vibrate** mode, press and hold "SPACE" key in main screen: the ringtone will then be disabled. Further long pressure on the same key brings the phone back to the previous mode.

Services

Services are provided with SIM kit, and this mobile phone supports service function. Detailed menu items depend on the SIM card and the network. When the network provides such function and your SIM card supports it, the **Service** menu content will automatically be posted in **Menu > Service**.

Caller groups

The caller groups in the mobile phone include various contacts sharing common characteristics and features (i.e. family, friends, work colleagues, etc.). You can create up to 20 caller groups and set different ringtones and pictures for each caller group.

To select a group, choose: **Phonebook > (Options) > Caller Groups > Add new group**. You can edit and rename each group, using the option **Group name**.

Note: you can add to the group phone contacts only – no SIM contacts.

Stand-by screen



Basic operations

Power on

Press the **On/Off** key for a few seconds to start the mobile phone.

From main menu, select **Settings > Dual SIM settings** to choose between: **Dual SIM open**, **Only SIM1 open**, **Only SIM2 open** or **Flight mode**. The defaulted mode is **Dual SIM Open**, if both SIM cards are inserted.

If a SIM card is inserted, the mobile phone will automatically check the SIM card availability and then the following informations will be show the on the display by sequence:

1. **"Input phone password"**— if you have set a password for the phone.
2. **"Input PIN"** —if you have set the telephone to ask for the SIM card password.
3. **"No service"**— indicates failure to register; the phone cannot make any calls.
4. **"Emergency calls only"**— indicates that the phone has registered to other network and can only make emergency calls to 112.
5. **"Searching"**— the mobile phone is searching for a network.
6. **"Operator name"**— indicates network successfully registered.


Note: if you do not know your PIN code, please contact the network service provider. The mobile default password code is "1122".

Power off

To switch off the mobile phone, press the **End/On/Off** key. When the screen displays the switch-off animation, the primary and the secondary SIM cards will be turned off at the same time. Do not take out the battery to switch off the mobile phone. If so, the SIM cards can be easily damaged and data could get lost.

Dial a call

- With the virtual keypad, you can directly enter phone numbers (if inserting a wrong character, press the “←” key to delete it). Press call key **SIM1** or **SIM2** to call the dialed number. To end a call, press the **END** key.
After the call is connected, you can see the call timer on the screen. If your dialed number is saved in mobile phone memory, the contact name will be displayed on screen.



- Dialling a call through the **Phonebook**: press **Names** key from main menu, to open **Phonebook** menu and search the desired name/phone. Choose **Call** and then **SIM1** or **SIM2**.
- Redial latest dialed number: in standby state, press **Call** key (**SIM1** or **SIM2**) to view the list of the 20 latest dialed phone numbers or names . The call history gathers all the calls as **Dialed calls**, **Received calls** and **Missed calls** (distinguished by different icons). Browse the list using the **navigation key** until you find the desired number; press Options > **SIM1** or **SIM2** to call it back.

Adjust receiver volume

When speaking to someone, press the **Volume** icon to adjust the receiver volume.



Answer a call

When there is an incoming call, you will be alerted with ring, vibration, vibration and ring, or vibration then ring, according to the settings of the mobile phone.

To receive a call, press the **call** key. To reject a call before answering, press the **END** key.

If the CLI (Call Line Identity) is opened, the phone number of the caller will be shown on the screen. If this number has been saved in the phonebook, the name corresponding to this number will be displayed on the screen. Pressing the **OK/Main** key, you will access an **Options** screen, where you are allowed to put on hold the current call, connect to another incoming call, record a call, enable the background sounds (to recreate the realistic ambient sounds during a particular call, i.e. "platform" "airport", "station", "restaurant" and other user-recordable sounds), or reject the call with an SMS.

Options for phone conversations

Select "**Options**" during conversation to access the following menu:

- **Hold single call:** to activate the function allowing to place a call on hold
- **End single call:** to end the call
- **New call:** opens the dialing interface
- **Phonebook:** opens the phonebook
- **Messaging:** opens the messaging folder
- **Sound recorder:** opens the recorder that can record the current conversation
- **Background sound:** opens the background sound utility
- **DTMF:** activates/deactivates DTMF signal sending

Note: some menu's elements need the network support; others may occur under special conditions. Please contact the network operator for further details.

DTMF tones

With this option enabled, when calling up a voice mailbox or another automated phone system press the desired number key and the "*" and "#" keys to send DTMF (Dual Tone Multi-Frequency) tones, in order to access options or extension numbers through telephone switchboards.

SMS Reading

A full screen pop-up will notify when the user receives a new SMS. Press **OK key** to open and read the message at once.

Missed calls


When there is a missed call, the screen will display a missed call icon (separately for SIM1 and SIM2). Press **OK key** to enter and read details about the missed call.

Answering machine

The telephone answering machine is a device designed to record audio messages directly on its local memory without connecting to a server to listen the recordings, thus avoiding the relative charges. Moreover, you can customize your answering machine message, using the phone's microphone. The answering machine will turn on after a preset number of rings, or can be operated manually as answer option. You will be notified with an icon (separately for SIM1 and SIM2) when you got messages left on your answering machine. If you want to listen to messages, select **NGM > Answer machine**.

Main menu

Use **OK/Main** key to access the Main menu of Soap Evo. Swipe the pages to left and to the right in order to browse between the three menu pages. By pressing the Main Key again, the Menu can be visualized in other two ways: Star travel and Tornado.



Phonebook

Contacts can be saved to the SIM card or phone memory. Use **Add new contact** option to add a new contact to your phone book. The phone book will show all the contacts from the SIM cards and phone. Only two details (name and phone number) can be saved to the SIM card. More details can be stored in the phone memory, including multiple phone numbers, email address, pictures, and ring tones.

The phone stores up to 1000 entries. The SIM cards store an additional 250 entries each.

Available options for the contacts (press **Main/OK** key):

- **View:** display the contact name, the number, and other details.
- **Send message:** send a SMS or a MMS to the selected contact.
- **Call:** call the selected contact.
- **Edit:** edit the details of the selected contact.
- **Delete:** delete the selected contact from the list.
- **Copy:** copy the selected contact from a memory to another (phone, SIM card, memory card); moreover, you can copy that same contact in a file (.vcf format) and save it in a location of your choice.
- **Move:** move the selected contact from a memory to another (phone, SIM card, memory card).
- **Send vCard:** send the **vCard** of the selected contact as text message, as multimedia message, as Email or via Bluetooth.
- **Mark several:** you can select more than one contact at a time to speed up the operations on the phone book.
- **Caller groups:** select **Add new group** to create up to 20 groups, and customize the attributes for each group. You can choose a name, a ring tone and a picture for each group (**Group settings**). Only contacts from the phone memory can be added to caller groups.
- **Phonebook backup:**
 - **Phonebook import:** contacts previously exported to the phone memory or to the memory card can be imported in the Phonebook.
 - **Phonebook export:** contacts saved in the Phonebook can be exported to the phone memory or to the memory card, in the **PhoneBook** folder (autocreated). To select the whole Phonebook, select **Phonebook export > Mark several > Options > Select all**. Then, select **Phone** or **Memory card** in **Options**.
- **Phonebook settings:**
 - **Name filter:** you can select which list to display (SIM1, SIM2, phone, memory card and all the possible combinations).
 - **Speed dial:** you can toggle this option on and off; it allows to assign a phone number to each numeric key (2-9) for speed dials.
 - **My vCard:** you can edit and send your vCard.
 - **Extra numbers:** you can view (separately for SIM1 and SIM2) some particular numbers as service numbers and SOS numbers. You can also edit your own number.
 - **Memory status:** you can display the current status of the phone book memory, the memory available on SIM1 and SIM2, and also the memory card. The display format for the memory usage is "used/total".

- **Copy contacts:** copy contacts from SIM to phone, from phone to SIM or from SIM to SIM.
- **Move contacts:** move contacts from SIM to phone, from phone to SIM or from SIM to SIM.
- **Delete contacts:** delete contacts from SIM cards or from phone.
- **Birthday notification:** you can set a birthday alarm to remind you at a specific time about the birthday of all the contacts you inserted in the phone memory.

Messages

SMS

Both SIM cards are able to send and receive SMS. When an SMS message is sent from a mobile phone, it will reach an SMS center first. The SMS center then forwards the SMS message towards the destination. If the recipient is unavailable (for example, when the mobile phone is switched off), the SMS center will store the SMS message. It will forward the SMS message when the recipient is available. The storage duration of the message depends on sender's settings and network operator's policy.

Sending and receiving text messages can become costly depending upon the text message plan you have with your provider. Please contact your service provider/network operator for further details. If SMS storage capability is exhausted, a SMS icon will flash in standby screen. Unnecessary SMS storage can affect the reception of new SMS; please delete older messages to prevent such problems. When a message has been received, you will get an SMS notification message (if the option has been previously selected).

Note: when sending SMS, the phone will usually show the "Message sent" notification. This means that the SMS has been sent to the SMS Center, but the message could anyway not be received by recipients. Please contact your service provider/network operator for further details.

MMS


MMS is a standard way to send messages that include multimedia content (short video clips, photos and audio). If MMS is over the size limit, the phone won't display the message. The phone will automatically resize the images attached to the MMS, so that they can be fully shown on the screen.

The visualization of each single MMS depends heavily upon the receiving devices.

Note: you can't send or receive multimedia content if your network operator/service provider does not support this service. Multimedia content can't be received or shown if the recipient doesn't have a MMS-compatible cell phone.

Write message

Select this option to write a new text message or a multimedia message. This device implements the T9 input mode, an advanced predictive text method for quickening and simplifying the whole message writing process.

Each SMS can contain at most 160 characters; by linking two or more messages together (up to a maximum of 8, after that the message is automatically converted in MMS) you can build a combined message (up to a maximum of 1140 characters). Press the "  " key to change the input method and the capital/small letters input. Press the ← key to delete the last entry; press and hold to clear it all.

If the text contains more than 160 characters will be split into two or more parties. You can insert pictures, animations, sounds, etc. within an SMS. However, the SMS won't be received and displayed if the network and the receiving phone do not support it. To send an SMS/MMS, enter a number directly or choose a number from the phonebook. In dual-SIM, you can choose to send SMS/MMS via SIM1 or SIM2 away.

Available options:

- **Send to:** send a message, inserting the addressee (typing or retrieving it from Phonebook).
- **Insert symbol:** insert one symbol in the text.
- **Input method options:** enable/disable from here the XT9 input mode and some of its features.
 - **Writing language:** the phone has the Italian language and input method as default. For different areas, there are other 4 different languages and the corresponding input method.
 - **Set XT9:** On or Off
 - **XT9 advanced settings:** enable/disable Auto-capitalization, Auto-completion, Auto-punctuation, and Word reselection.

- **Auto-correction:** Off , Low or High; this feature sets the degree of auto-correction.
- **Add picture:** add a picture to the message
- **Add sound:** add an audio file to the message
- **Add video:** add a video file to the message
- **Add subject:** add a subject to the message
- **Slide options:** to insert or delete images in a sequence
- **Switch to MMS:** jump to the screen of multimedia composition.
- **Advanced:** to insert text template, attachment, contact number, contact name, or a bookmark.
- **Save:** save the message to SIM1 or SIM2.
- **Details:** view some details about the message.

Inbox

In this menu you can view the SMS/MMS list of the received messages.

Available **Options:**

- **View:** open the selected conversation.
- **Reply:** send a message to the sender of the selected message.
- **Call sender:** make a phonecall to the sender.
- **Forward:** forwards the selected message.
- **Delete:** deletes the selected message.
- **Delete all:** deletes all messages.
- **Save to Phonebook:** saves the phone number of the sender of the message.
- **Mark several:** marks more than one message.
- **Mark as unread:** marks the selected message as unread.
- **Advanced:** copies or moves the selected message/es
- **Details:** shows message details such as sender, type, date and storage.

Drafts

Use the Drafts folder to save messages you're still working on, before you send them. You can send, edit, delete or apply the Advanced options to the messages saved in this folder.

Outgoing

All the messages that for some reason can't be immediately sent, are temporarily saved in this folder. You can send, edit, delete or apply the Advanced options to the messages saved in this folder.

Outbox

The sent messages are stored here.

JunkBox

Unwanted messages are saved into this folder, where you can view them sorted also by contact name or by SIM card of reception.

Delete messages

Delete messages globally, or selectively (received, drafts, sent, etc.).

Email

See paragraph "E-mail"

Broadcast messages

Activate this function to receive broadcast messages. These messages are sent to every device on a network and usually contain information as weather forecasts, traffic conditions, etc.

Templates

Some ready-to-use templates are available, for various situations (SMS and MMS).

Message settings

Use this submenu for setting text and multimedia message options (separately for SIM1 and SIM2).

Text message

Available options for **SIM1** and **SIM2**:

- **Profile settings:** set the SMS/MMS Center number before sending and receiving SMS e MMS
Note: this number is provided by the network operator.
- **Voicemail server:** set name and number for the voicemail server.
- **Common settings**
 - **Delivery report:** it is a notification sent to you that lets you know when your text message has been delivered to the recipient, and when.
 - **Reply path:** when the receiver of your SMS responds, it knows what SMS gateway to send the reply back to. This option requires SMS Center support.
 - **Save sent message:** a copy of each message that you send will be saved in the **Outbox** folder.
- **Memory status:** check here memory capacity on SIM card and Phone, related to the messages.
- **Preferred storage:** select the storage path for message files (Phone or SIM card).

Multimedia message

Available options:

- **Data account :** select a data account to be used for MMS sending, one for each SIM.
- **Common settings:** define some parameters describing **Composing** methods (slide time, creation mode, picture resizing, auto signature, etc.), **Sending** (validity period, delivery report, reading report, priority, etc.), **Retrieval** (home network, roaming, filters, delivery report, reading report, etc.), **Preferred storage** and **Memory status** for MMS.

Service message

From this menu, you can enable/disable the **Push mail** service, choose the **Service loading** mode, and enable/disable the **White List**.

Conversations

From this menu, you can enable/disable the **Conversations** feature. If disabled, the messages will be shown on the menu in a separate way, as **Inbox**, **Outbox** and **Sent messages**.

Call logs

In dual-SIM mode, you can separately search the call register of SIM1 and SIM2 and set separately some operations corresponding to SIM1 and SIM2. In mono-SIM standby mode, you can set the available SIM card and see its call register. Call history is shown as three separated lists: **Dialed calls**, **Received calls** and **Missed**

calls. Browse the lists using the **navigation keys** (up/down); when you find the desired number, press SIM1 or SIM2 key to call it back.

Available options for each call in the lists:

- **View:** view the call details
- **Call:** call the selected number
- **Send message:** send a text message or a MMS to the caller
- **Save to Phonebook:** save the caller's number in your phone book (if not already saved)
- **Save to Blacklist:** add the caller's number to the Black List (calls or SMS), selectively for SIM1 and SIM2; see **NGM special functions** paragraph
- **Save to Whitelist:** add the caller's number to the White List (calls or SMS), selectively for SIM1 and SIM2; see **NGM special functions** paragraph.
- **Edit before call:** edit the selected number before calling
- **Delete:** delete the call from the list
- **Advanced:** see details about Call timers, Call costs, Text message counter and GPRS counter).

Call timers (separately for each SIM)

- **Last call:** with this function, you can view the last call duration.
- **Dialed calls:** with this function, you can view the global duration of all dialed calls.
- **Received calls:** with this function, you can view the global duration of all received calls.
- **Reset all:** with this function, you can clear all your call duration records.

Call cost

This function needs the support of the network service provider.

- **Last call cost:** with this function, you can view the last call cost.
- **Total cost:** with this function, you can view the global cost of all dialed calls.
- **Reset cost:** with this function, you can clear all your call cost records (PIN2 code requested).
- **Max cost:** with this function, you can limit call costs in the specified pricing unit or currency unit. PIN2 code must be input to set call cost.
- **Price per unit:** this function needs network support. For more details, please consult the network operator.

Note: *real call's duration and time/cost counting for billing purpose on the network operator side may differ: this can be attributed to network functions, bill roundings, taxes, etc.*

Text message counter

With this function, you can view the number of **sent** messages and **received** messages, separately for each SIM.

GPRS counter (SIM1 and SIM2)

- **Last sent:** you are able to view traffic sent in the last GPRS connection.
- **Last received:** you are able to view traffic received in the last GPRS connection.
- **All sent:** you are able to view global traffic sent.
- **All received:** you are able to view global traffic received.
- **Reset counter:** you can clear all your traffic data records.

Dialer

Opens the Virtual Keypad, see paragraph "virtual standard keypad".

NGM – Special Functions

Calls & SMS firewall

- ✓ The **Black List** of contacts (phone numbers) allows everyone to call you or send messages to you, except for the members of the Black List.
When this access control function is active, a blacklisted caller will just hear busy tone all the time; later, you will get a network SMS alert (if allowed in your network services) informing you about the number of the caller who was trying to contact you. Messages received from a blacklisted number will be automatically transferred to the **Junkbox** folder.
- ✓ The **White List** of contacts allows nobody to call you or send messages to you, except for the members of the White List. When this access control function is active, a non-whitelisted caller will just hear busy tone all the time; later, you will get a network SMS alert (if allowed in your network services) informing you about the number of the caller who was trying to contact you.
Messages received from a non-whitelisted number will be automatically transferred to the **Junkbox** folder. Regardless of White and Black list, you can also block the calls coming from anonymous callers or from callers not stored in the Phonebook.

SIM1/SIM2

Here you can set and enable, separately for each SIM, a Black List and a White List, for Messages as well as for Calls.

- **Calls:** Create a **Black/White** list for incoming calls: add the contacts to the Black or White List.
 - **Settings:** here you can enable/disable the following firewall combinations : The option **Firewall close** allows to disable at the same time all the firewall combinations previously enabled. **Blacklist State, Whitelist State** activate the Black or White lists. **Block not in Phonebook, Block anonymous number, Blacklist and Block not in Phonebook. Black List and Block anonymous number.**
- **SMS:** add the contacts to the Black or White List.
 - **Settings:** here you can enable/disable the following firewall combinations : **Black List, White List, Numbers not stored in the Phonebook, Black List +not stored in the Phonebook.** The option **Firewall close** allows to disable at the same time all the firewall combinations previously enabled.

Note: when the firewall type has been selected, you will be requested to set (if you want) the Activation Time and the Rejection Method (for the Calls Firewall).

Phone control

Phone Control is a function that has been designed to improve mobile device users' privacy and security. It is composed of two applications (**SIM binding and Remote Control**, plus **Trusted Numbers**), allowing the user to manage security in different modes.

- **SIM binding:** The SIM binding function is offered to help end-user to find his phone in case it has been lost or stolen. The function is based on the binding between SIM card and phone: the device is able to recognize when a different SIM card is inserted into the phone and immediately alerts by SMS the 5 trusted numbers previously set by the owner. By activating this option, the phone password will be requested (1122 preset, changeable in **Settings > Security settings > Change password**). The user must first insert at least one trusted number for SMS notification. From **Phone Control** menu, select "**Trusted Numbers**" and insert up to 5 phone numbers to receive the message. Select "**Activation**" in SIM Binding and choose "**On**" to enable the function.
After completing the configuration, at every start-up the phone will check the presence of the SIM cards to which it is bound to. If the two SIM cards are inverted or one of them has been removed, the phone still starts regularly.

If a not-bound SIM card is inserted into the SIM1 or SIM2 slot, the phone shall display the "Input phone password" popup (the default password is **1122**, freely modifiable by user). If the password is correctly inserted, the phone starts regularly, but a popup will advise the user that the SIM card is changed: "SIM card is changed. Do you want to bind it?" Choosing "Yes", the current SIM cards will be bound replacing the old ones; choosing "No", the old binding will remain active.

In case the wrong password is inserted, the phone will normally start and provide the "new" user all the functionalities except for the "**Phone control**" menu. In the meantime, an alert SMS (- "Attention: this phone number is using your mobile phone IMEI: XXXXXXXXXXXXXXXX" -) will be sent to all the trusted phone numbers set in the menu from each replaced SIM card. Every time the power on password is wrongly inserted, the phone will continue to send out alert SMS. If SIM1 has no money or is out of range, SIM2 will provide to send the alert SMS. If the SMS is not correctly sent out for any reason, the phone will attempt to send the SMS out periodically, until the SMS is correctly sent out.

Note: if **Phone lock** is enabled, this function chronologically comes before SIM binding. This means that even if the SIM binding is activated, it will be unavailable if the wrong password is inserted (because the phone simply won't boot).

Tip: to avoid this problem, it's advisable to disable **Phone lock** and enable **Privacy firewall** instead, since this function assures the same high level of data security and does not inhibit the use of SIM binding.

- **Remote Control:**

The user must first insert at least one number for SMS notification. The Remote control function is offered to provide end-user the possibility to manage some phone functions remotely from another phone able to send SMS out. Using this function, end user can, when he has not the phone with him, forward calls, power the phone off or activate the answering machine.

By activating this option, the phone password will be requested (1122). Please refer to the paragraph "Security settings" in the chapter "Settings" for the instructions on how to modify this password.

Select "**Activation**" and choose "**On**" to enable the function.

- **Trusted Numbers:** insert up to 5 phone numbers and edit and rename them as you wish with **Options**.

After completing configuration, the phone will accept the following remote commands from one of the trusted numbers.

1) Call forwarding

If the user wants to forward all the incoming calls to another number, he can send to the NGM phone (with its remote control enabled) an SMS containing the following text:

***#CALLFWD*#destination number**, where "destination number" is the number where the user wants to receive the forwarded calls.

Example:

- if the phone number with the NGM remote control enabled is +390000000000;
- if the phone number to remotely control the phone is +391111111111 (**trusted number**);
- if the phone number where you want to forward the calls is +392222222222.

The operations sequence shall be:

- a) +391111111111 send one SMS to +390000000000 with the content: ***#CALLFWD*#2222222222**.
- b) +390000000000 receive one SMS from +391111111111 and automatically set the forwarding to +392222222222.
- c) all the incoming calls to +390000000000 shall be forwarded to +392222222222.

Note: the SMS content is "case insensitive", so it may be indifferently written with capital letters, lower-case letters or a combination of the two.

2) Remote shutdown (and activate the phone password at power on)

If the user wants to remotely shut down the phone, he can send to the NGM Phone (with its remote control enabled) an SMS containing the following text:

***#SHUTDOWN*#**

Example:

- if the phone number with the NGM remote control enabled is +390000000000;
- if the phone number to remotely control the phone is +391111111111 (**trusted number**).

The operations sequence shall be:

- a) +391111111111 send one SMS to +390000000000 with the content: ***#SHUTDOWN*#**.
- b) +390000000000 receive one SMS from +391111111111 and automatically shut down.
- c) the phone password is automatically activated, so that it will require the use of the password at the next start-up. If the password is correctly inserted, the phone shall start regularly, and won't require the use of the password anymore (except for the case of the user that choose this particular setting).

Note: the SMS content is "case insensitive", so it may be indifferently written with capital letters, lower-case letters or a combination of the two.

3) Activate the answering machine

If the user wants to record all the incoming calls on the answering machine, he can send to the NGM Phone (with remote control enabled) an SMS containing the following text:

***#ANSW*#**

Example:

- if the phone number with the NGM remote control enabled is +390000000000;
- if the phone number to remotely control the phone is +391111111111 (**trusted number**).

The operations sequence shall be:

- d) +391111111111 send one SMS to +390000000000 with the content: ***#ANSW*#**.
- e) +390000000000 receive one SMS from +391111111111 and automatically activate the answering machine for both the SIM cards.
- f) all the incoming calls on +390000000000 shall be recorded on the answering machine.

Note: the SMS content is "case insensitive", so it may be indifferently written with capital letters, lower-case letters or a combination of the two.

Privacy firewall

After digiting the phone password (the default password is "1122"), you can enable/disable from here the locking on Phonebook, Messages, Call History and the Keypad encryption.

Answering machine

The built-in Answering machine allows people to leave voice messages for you when you can't answer your phone.

- **Messages:** Here you can listen to the recorded phone message that are stored in memory.
- **SIM1/SIM2 Settings:** From here, you can toggle on/off the auto answer, select the storage path, fix the pickup time (3, 5, 10 or 30 seconds), fix the record duration (30 seconds, 1 minute, 3 minutes, 5 minutes or unlimited), use the default greeting message or select one from your audio files, enable/disable remote access using any DTMF telephone.
For the remote access, with the above said option enabled, you need a DTMF (touchtone) telephone. When the answering machine has picked up the call, you'll hear the invitation to leave a message; at this point you can digit "#" and then wait for the prompt to digit your password (**1234** as default).

Note: remote access supports listening only.

Chat

Here you can see the chronology of messages sent and received with a contact.

Background sound

Background sounds help to recreate the realistic ambient sounds during a particular call (e.g. "platform" "airport", "station", "restaurant" and other user-recordable sounds). This option can be selected by default or can be set when there is an incoming call.

You can control the volume level and reproduction mode (once, continuous, interval). The phone includes 10 pre-recorded background sounds; user can add his own sounds in .wav format (8 MHz, 16 bits samples).

SMS delayed sending

You can postpone sending a SMS message, scheduling the sending at a particular date and time. You can also specify multiple recipients, set the repetition of sending, and choose which SIM to use.

Wi-Fi

This phone is able to connect to a wireless network and then to an access point for the Internet browsing. This allows the user to move within an area of local coverage and stay connected to the network. When you open this option from the main menu or using the shortcut on the widgets bar, the phone will automatically detect the available networks, with their relative signal strength. For each detected network the following options are available:

- **Connect:** to connect to the selected network.
- **Add:** set the parameters for a new access point.
- **Define Access Point:** edit the parameters for the access point.
- **WiFi status:** view the details of the connection.
- **Disable Wi-Fi:** turn off the Wi-Fi radio module.
- **Refresh:** update the search for available networks.

Bluetooth

The phone supports Bluetooth™. Bluetooth is a short-range radio transmission system that is useful for sending data between electronic devices, as cell phones, computers, earphones, car-kits, etc. Bluetooth allows to send photos, video clips, audio files, electronic business cards and reminders. You can also wirelessly connect to your PC and send files or establish a low-speed connection to the Internet.

When a Bluetooth connection is established, the distance between the communicating Bluetooth devices must be usually not more than 10 meters to guarantee optimal performance. In any case, walls and other solid barriers can shield the Bluetooth connection, and other electronic devices can cause interference. In order to verify the full compatibility of this phone with other Bluetooth devices, please check with the device's manufacturer for the latest information. Do not use Bluetooth in the hospitals, on aircrafts, etc.

- **Power:** turn the Bluetooth power on, before using this function. When not in use, Bluetooth power consumption could be rather high. So, it is advisable to turn off Bluetooth function when you are not using it.
- **Visibility:** when Visibility is on, other Bluetooth devices can detect your phone and its name after starting a search. If the audio player is on, your device will be undetectable.

- **My device:** with this function you can see all the devices that have been paired with the phone in the course of time and their type of connection. The option **Inquiry new device** will start a search for all Bluetooth devices compatible with your phone, and will pair the phone with the selected Bluetooth device. It's obviously possible to cancel the unwanted connections.
- **Inquiry audio device:** with this function you can start a search for all the Bluetooth audio devices compatible with your phone. Then, you can pair the phone with the selected Bluetooth audio device. When searching for Bluetooth devices of another kind, please use the function **Inquiry new device** instead.
- **Change device name:** change the name with which your phone is detected by other Bluetooth devices.
- **Advanced:** prima di utilizzare la funzione Bluetooth, aprite questo menu per scegliere le impostazioni corrispondenti.
 - **Audio path:** set Audio path (Phone or Bluetooth headset).
 - **Storage:** set storage path for Bluetooth file transfer (Phone or Memory card).
 - **Sharing permission:** to determine whether people accessing the shared files via Bluetooth can do it in read-only mode or with all privileges.
 - **My address:** : display the Bluetooth address of your device.

Tip: when searching for other Bluetooth devices, make sure that the devices are inside the range reachable by Bluetooth signal. When pairing other devices, it shall be necessary to agree on a password shared with the Bluetooth devices' users. To pair the earphones with your phone, insert its own password.

Settings

User profiles

The phone has multiple profiles, in order to customize certain settings for different situations. First, you should change your settings to your liking for each profile, and then activate them. Available profiles: **General, Silent, Vibration, Meeting, Outdoor, Indoor, My Style, Headset, Bluetooth.**

The contents of each profile can be customized freely by tackling the following parameters:

- **SIM1/2 Alert type:** choose between Ring only, Vibrate only, Vibrate and ring, or Vibrate then ring.
- **SIM1/2 Ring type:** choose between Single, Beep once, Repeat or Ascending.
- **SIM1/2 Incoming call:** set the tone for incoming voice calls (SIM1 and SIM2).
- **SIM1/2 Ringtone volume:** adjust the ringer volume (SIM1 and SIM2).
- **SIM1/2 Message:** set the tone for Message tone (SIM1 and SIM2).
- **Message volume:** adjust the volume for Message tone.
- **Keypad:** choose between Tone or Click.
- **Keypad volume:** adjust the volume for Keypad tone.
- **Power on:** set the tone for Power On.
- **Power off:** set the tone for Power Off.
- **System alert:** enable/disable the tones for Warning, Error, Warning Sign SIM, and Acknowledgment of connection.
- **SMS repeat tone:** get a repeated warning of unread text message.

My style profile can be customized, reset and renamed as you prefer.

After making customizing your settings, click "**Activate**" to activate the selected profile.

Note: if the headset is inserted into the device, the phone will automatically switch to Headset Profile. When the headset is switched off, the phone returns to the previous profile.

*In standby mode, press and hold **SPACE** key to switch to Silent profile or return to the previous profile.*

Phone settings

Time and date:

With this function, you can set your time zone reference city, time and date format and the time of a specific foreign location.

- **Set Home City:** you can set your time zone reference city.
- **Set Time/Date:** you can set the current time and date, and activate/deactivate daylight saving.
- **Set Format:** you can set the format of date and time visualization.
- **Update with time zone:** to set the mobile phone to automatically update time and date according to the current time zone, choose "On". Auto update of time and date will not affect the alarm clock, calendar or alarm clock memo setting time, which will be subject to the time and date when created.

Note: if the battery is taken from the mobile phone or the battery is used up for long time, when switching on the mobile phone after reinstalling the battery or charging the battery, you will need to reset time and date.

Special note: please disable the automatic update in all areas where the cell phone use is forbidden.

Schedule Power on/off: you can schedule the Power on/off time by using the 4 timing slots.

Language: you can select the desired language for the phone's menus between the choices.

Preferred writing language: defines which language is available in **XT9 Settings**.

Display:

- **Wallpaper:** you can choose between 8 system-defined wallpapers or insert a user-defined one.
- **Screen saver:**
 - **Settings:** enable/disable the screen saver, and fix the waiting time (5 sec., 15 sec., 30 sec. or 1 minute).
 - **Select:** eight **System** screen savers are available as well as a **User defined** screen saver (previously saved in Phone or Memory card).
- **Power on picture:** choose the system-defined animation or insert a user-defined one.
- **Power off picture:** choose the system-defined animation or insert a user-defined one.
- **Show date and time:** to visualize (or not) the date and time on the stand-by display.
- **Clock type:** you can choose between digital and analog clock.
- **Show owner number:** You can turn on or off the display of the owner number separately for the two SIM Cards.

Greeting text: to visualize (or not) a greeting message whenever turning on the phone.

Auto update time: toggle on/off the automatic update of date and time. This updating doesn't affect alarm clock or calendar. The update must be supported by network operator.

UART settings: enable the UART settings on one of the two SIM cards.

LCD Backlight: you can adjust the LCD backlight brightness and timing (5 sec. ~ 1 minute).

Dual SIM settings

At any time you can set the desired mode on the mobile phone, according to the following options:

- **Dual SIM open**
- **Only SIM1 open**
- **Only SIM2 open**
- **Flight mode**

In Flight mode the SIM cards are disabled, but the other functions are still available.

Touch calibration

Follow the instructions in order to calibrate the touch screen.

Network settings

Network Configuration SIM1 / SIM2:

For each of the two SIM options are available:

- **Network selection:** you can decide whether to make a manual or automatic selection.
- **Preferred Networks:** You can create a list of preferred networks that register.

Note: Other options may be available depending on the operator to each SIM.

Security settings

Security settings SIM1 / SIM2

- **SIM1 / SIM2 lock:**
From this section you can set the phone to ask for the PIN each time or not.
- **Change password:**
 - **SIM PIN:** you can change the PIN code of each SIM.
 - **SIM PIN2:** you can change the PIN2 code of each SIM.

Call settings

In dual-SIM mode, you can maintain separate **Settings** for SIM1 and SIM2.

Note: these functions require network support.

- **Caller ID:** you can choose ID as **Set by network**, **Hide ID** or **Send ID**.
- **Call Waiting:** you can freely choose to turn On or Off this function. The call hold cannot be active unless this function is activated. This function requires network support.
- **Call Divert:** this kind of function cannot be used unless you apply to the network operator for it. With this function, you can divert calls meeting the following conditions to another number:

Condition	Description
Divert all voice calls	The network will divert all voice calls without conditions.
Divert if unreachable	When the network cannot find your mobile phone (switched-off or out of the service area), it will divert the calls.
Divert if no answer	When the mobile phone does not answer the call, the network will automatically divert it.
Divert if busy	When you already are in a conversation, the network will divert the call.

Divert all data calls	The network will divert all data calls without conditions.
Cancel all divers	Cancel all divert conditions.

- **Call Barring:** enable/disable block on outgoing calls (all, only international calls, international calls except to home) and/or incoming calls (all or when in roaming). These options require a password (1122 as default), freely modifiable by user

Advanced settings:

- **Auto redial:** you can set this function as On or Off. After the first automatic redial fails, you can have at most ten times to connect a phone number.
- **Call time display:** the phone screen can display the talking time of your current call.
- **Call time reminder:** : the phone has time reminder: you can set a sound warning at any time you like or at any time interval (between 30-60 seconds).
- **Reject by SMS:** : you can automatically reject a call by SMS, using a predefined message to select in **Messages > Templates**.
- **Connect notice:** this option allows to get an advice when the connection is established.
- **Answer mode:** this option allows to answer a call by pressing any key, or to enable the Auto answer when in headset mode.

Note: some settings require network support.

Phone lock

You can set up the phone lock, digiting the requested password (the default password is "1122"). When the lock is enabled, the phone will prompt you for your password before you can make or receive calls. Insert the default password (or a personal one; see below how to change the password) to unlock, and confirm.

Change password

You can change here the password for the phone lock (the default password is "1122") with another one easier to remember and more secure. The new password has to be between 4-8 digits long.

Certificate manager

You can use **Certificate Manager** to see details about your certificates, modify them, delete them, or request new ones.

Restore factory settings

The password required to perform this operation is "1122".

- **Restore default settings:** reset your device to the original settings.
- **Delete all user data:** reset your device to the original settings and erase messages, phonebook and call logs.

Connectivity

Bluetooth:

see paragraph "Bluetooth"

WiFi:

see paragraph "WiFi"

Connection management:

Show and manage all connections currently active.

Data account:

You can set here the MMS/WAP/WEB account profiles for SIM1 and SIM2.

Available options:

- **Add PS account:** view, add or edit the following details of your GPRS account: account name, APN, user name, password, authentication type, SIM selection and Advanced settings (Homepage, Connection type, Proxy, Primary and Secondary DNS, IP address and Subnet mask).
- **Add CSD account:** view, add or edit the following details of your GSM account: account name, number, user name, password, line type, speed, SIM selection and Advanced settings (Homepage, Connection type, Proxy, Primary and Secondary DNS, IP address and Subnet mask).
- **Edit:** edit the selected MMS/WAP or WEB account.
- **Delete:** delete the selected MMS/WAP or WEB account.
- **Change default:** choose which MMS/WAP or WEB account to set as default.

Note: please contact your network operator for further details about settings and connection charges. Network services may vary from provider to provider and are subject to change.


Camera

This item gathers two functions: **Camera** and **Video recorder**.

Use the inbuilt camera to take your photos. The camera lens is on the back side of the phone and the LCD screen acts as a viewfinder. It is advisable to keep the phone in a horizontal position to view correctly the tools available on the LCD screen. The photos are saved in a JPG file format, videos in 3gp. Some software could be necessary to view the photos, if you download your camera phone pictures onto the computer.


If there is insufficient space on the drive to store the images, it should be necessary to remove some old pictures (or any other type of files) from "**File manager**" menu to free up disk space.

Camera screen:



Option	Description
Camera	
Switch to	Switch swiftly to Image viewer (photo album) or to Video recorder
Capture mode	Normal, Continuous shot, Burst shot selection
Image size	Wallpaper, VGA, 1MP, 2MP, 3MP
White balance	Auto, Daylight, Tungsten, Fluorescence, Cloudy or Incandescence
Effects	Normal, Grey scale, Sepia, Sepia green, Sepia blue, Color invert
Misc.	
Storage: Phone or Memory card.	
Image quality: High, Medium or Low.	
Shutter sound: Off, Sound 1, Sound 2 or Sound 3.	
Anti-flicker: 50Hz or 60Hz.	
Restore default settings: put the camera back to factory settings.	

Use the switching key to switch between Camera and Video recorder.



Option	Description
Video	
Switch to	Switch swiftly to Camera.
White balance	Auto, Daylight, Tungsten, Fluorescence, Cloudy, Incandescence.
Effects	Normal, Grey scale, Sepia, Sepia green, Sepia blue, Color invert
Misc.	
Storage: Phone or Memory card	
Video quality: High, Medium or Low	
Record audio: Off or On	
Anti-flicker: 50Hz or 60Hz	
Restore default settings: put the video recorder back to factory settings	

Image

Use this menu to view an image file previously saved in phone or memory card. This application supports JPG picture format. Available options:

Option	Description
View	View the selected picture.
Image information	Show some details about the selected picture (date, size, exposure, etc.).
Browsing style	List or matrix.
Send	Send the file as MMS or via Bluetooth.
Use as	Use the selected picture as wallpaper, as screen saver, power on/off picture or caller picture.
Rename	Rename the selected picture.
Delete	Delete the selected picture.
Sort by	Name, Type, Time or Size.
Delete all files	Delete all the image files from the chosen storage location.
Storage	Phone or Memory card.

When an image has been opened, you get access to the following **Options**:

Play	Shows the image
Use as	Use the selected picture as wallpaper, as screen saver, power on/off picture or caller picture.
Send	Send the file as MMS or via Bluetooth.

Image information	Show some details about the selected picture (date, size, exposure, etc.).
Help	Show infos about rotation, zoom in/out, move, etc.

Opera

Opera Mini™ is a web browser, based on the Java platform. Enter the URL of a site, and you can quickly access the Internet. Please check the correct setting of Java before using the browser.

See <http://www.opera.com> for further details.

Services

SIM Services

The first sections of **Services** menu are reserved to network operator services (SIM1 and SIM2), and therefore they may vary according to the quantity and type of options available.

WAP (Internet service)

■ **Homepage:** set the initial or main web page from where to start navigation.

■ **Bookmarks:** save a link to a web page (**Google** already linked). Available options:

- **Go to:** open the selected web page.
- **Edit:** edit the selected bookmark.
- **Send:** send the selected bookmark as SMS , as MMS, or as Email.
- **Delete:** delete the selected bookmark.
- **Delete all files:** delete all the bookmarks.
- **Add bookmark:** manually add a bookmark (specify title and web address).

■ **Recent pages:** show the last 10 web pages visited.

■ **Offline pages:** display information that is accessible when you are not connected to the Internet. The web pages have to be saved during the navigation for viewing offline.

■ **Input address:** manually add a web address.

■ **Service inbox:** get service infos from the network operator (e.g. head news referred to specific arguments, web links, etc.).

■ **Settings:**

- **Select SIM:** SIM1, SIM2 or Always ask
- **Profiles:** select an account from the list or add a new one. The selected account may be activate or edited. To edit an existing account or insert a new one, you need filling the following fields:
 - ✓ **Profile name:** choose a name.
 - ✓ **Homepage:** set the initial web page for this profile.
 - ✓ **Data account:** set the network ID.
 - ✓ **Connection type:** HTTP or WAP.
 - ✓ **User name:** insert user name, if required.
 - ✓ **Password:** insert password, if required.
- **Browser options :** set up a time-out, enable/disable loading images, enable/disable cache and cookies.

- **Service message settings:** enable/disable push notifications, enable/disable service message loading, enable/disable messages from trusted addresses only (White List), build a White List.
- **Clear cache:** remove file contents from the cache.
- **Clear cookies:** delete cookie files.
- **Trusted certificates:** view the list of trusted certificates.

Licence manager

In this section you can view and manage all the licenses related to the connection services.

Nimbuzz

Nimbuzz™ offers instant messaging, VoIP, social networking, file sharing and chat. You can use it to connect with instant messaging communities and many social networks.

Maps

Google Maps™ allows you to search for a variety of different kinds of places, simply using your cell phone.

Java

In **Java Applications** are gathered applications as Google Maps, Nimbuzz and Opera Mini.

In **Settings** and **Java default security** you can edit the configuration, view the details, change the network profile, and restore the factory settings (for all the Java applications at the same time).

Calendar

With this function, you can set the alarm clock to keep track of your schedule and record your monthly schedule. Roll the highlight block to the desired date and then the current date will be highlighted in red. To view all memos of one day, select the date, press Multifunction key, and then select **View all**.

Available options:

- **View:** you can view the schedule of the date where the cursor is on, and set the time, date, content and whether to activate alarm on this schedule of today's. When editing the schedule, you can choose an alarm type with the left and right direction keys. In addition, you can have such operations as Delete, Delete and Add on the schedule.
- **View all:** you can view the entire schedule of the date where the cursor is on and set the time, date, content and whether to activate alarm on this schedule. The options available are the same as the previous feature.
- **Add event:** you can select the type of task to memorize (Reminder, Meeting, Course) and set start/end date and hour, subject of the task, activate/deactivate alarm, set the frequency for repeating, location and priority.
- **Delete event:** you can delete the selected task.
- **Jump to date:** you can move the cursor to the specified date on the calendar.
- **Go to today:** jump to the current date.
- **Go to weekly/monthly view:** switch between the weekly and monthly views.

File manager

With File manager, you can manage the contents and properties of files and folders on your device memory and memory card.

[Phone] -- the storage path is the phone memory.

[Memory card] -- the storage path is the memory card.

For each **storage path**, the available options are:

- **Open**: view the root directory.
- **Format**: formatting will remove all the data from memory card or phone, including the folders created by user. After formatting, you'll need to reboot the phone; **Audio** and **Images** folders will be automatically restored, and the folder **Photos** will be automatically created after the first shot.
- **Rename**: rename an existing folder.
- **Details**: display the free space and the total capacity of the selected drive.

From **root directory** of each storage path, the available options are:

- **Open**: open folder (Video, Audio, Music, Photos, Received, etc.)
- **New folder**: create a new folder in the root directory.
- **Rename**: rename an existing folder.
- **Delete**: delete an existing folder.
- **Sort by**: sort the folders by Name, Type, Time or Size, or let them unsorted.

Inside any **folder**, the files options available are the same already described in the paragraphs dedicated to each multimedia applications (**Camera, Video player, Music, Ebook reader, etc.**), plus the following ones:

- **New folder**: create a new sub-folder.
- **Rename**: rename a file in the list.
- **Delete**: delete a file in the list.
- **Sort by**: sort the files by Name, Type, Time or Size, or let them unsorted
- **Mark several**: to select a list of files at one time.
- **Copy**: copy the file(s) in another folder.
- **Move**: move the file(s) in another folder.
- **Delete all files**: delete all the files in the current folder.
- **Details**: view the details of the selected file (date, size, copyright).

These options are available in all the folders, including user created folders.

Alarm

The time format for the alarm clock is identical to that of clock. When the mobile phone is off, the alarm clock can still work provided the battery is sufficient. The system has set 5 alarm clock options and the defaulted is off. You can activate one option or all options according to the actual demand. Every alarm clock option can set independent time and date. When the time is reached, the mobile phone will give out alert tone and flicker the current time on the screen. Press **Stop** to stop alarm clock; press **Snooze**, then the mobile phone will pause ringing and continue after a given time period.

If alarm time is reached but the mobile phone is switched off, then the mobile phone will be switch on automatically and ring. If Stop is pressed, then the mobile phone will ask you whether to switch on the mobile phone. Press "No" to switch off the mobile phone and "Yes" to register at the network and switch on the mobile phone.

Media player

From this menu you can choose to play audio files saved stored on phone or on memory card. To download files from your PC, T-Flash card must be inserted on the phone; then shut down the phone and connect it to your computer with the USB cable; the computer will detect the mobile phone automatically as a Mass Storage device. Download the desired MP3 files in "**My Music**" folder of the Memory card, otherwise the audio file will not play. Audio Player supports MP3, AMR, 3gp, WAW, AWB, AVI, MIDI. If the operating system of your PC is Windows 2000 or later, any driver is required.

- **Now playing:** open the media player (audio and video).
- **All songs:** before reading audio files is necessary to search via "**All songs**" the music files to be read: then, select **Options**, then **Add to folder**; select (for instance) the memory card and choose again **Options > Select** to select the whole folder. The audio content of this folder will be now shown in **All songs**, and the fields Artists, Albums and Genres will show the available informations.
- **Artists:** display the songs in "My music" folder by artist.
- **Album:** display the songs in "My music" folder by album title.
- **Genres:** display the songs in "My music" folder by genre.
- **Playlists:** create a playlist of favourite tracks, or listen to the most played, the recently played, or the recently added tracks.
- **All videos:** just as per "**All songs**", search first the video files to be read, using **All videos** and **Options > Select**. The video content of the folder will be now shown in **All videos**.
- **Refresh library:** refresh the library, according to the changes made in "My music" folder.
- **Settings:**
 - **Player:** enable/disable repeat mode, shuffle mode, sound effects and bass enhancement.
 - **Audio:** change the display style of the player.
 - **Bluetooth:** BT stereo output and BT stereo headset.
 - **SRS:** SRS WOW HD software enhances your audio to make it sound best through the speaker or ear plugs (9 different equalizer settings available)
- **Reset library:** reset the whole audio and video libraries.

Sound recorder

Use this menu to start a new audio recording and play audio files previously saved in phone or memory card. Press the central key to get the following options:

- **New record:** start a new audio recording.
- **List:** display all the files in the list
- **Settings:** select storage path (phone or memory card), audio recording format (AMR, AWB o WAV) and audio quality.

After recording an audio file, you will get also the options: Play, Append (combine two recorded files into one single file), Rename, Delete, Use as (incoming call SIM1/SIM2), Send (as MMS, as E-mail or via Bluetooth).

FM Radio

The phone includes a built-in FM radio. The earphones are required to listen to FM Radio: insert first the earphones jack in the socket on the right side of the phone. The earphones cable acts as antenna, so let it hang free from the connector. It is possible to make/receive a telephone call when you are listening to the radio. When the conversation is rolling along, radio will automatically switch to silent mode. If some application is currently using GPRS or CSD to send/receive data, there could be interference with radio signal.

After starting FM radio, the phone will show number, name (if already saved), and frequency of the radio channel. If you already saved some radio channels into the phone (max. 30), you can select the desired channel.

Options

- **Channel list:** save up to 20 radio channels

- **Manual input:** insert here directly a specific radio frequency . The frequency range of FM (frequency modulation) radio is 87.5 MHz to 108 MHz.
- **Auto search:** start an automatic search and save the frequency in the Channel list.
- **Settings:** enable/disable loudspeaker, choose a recording format, choose audio quality and select the storage path for the recordings.
- **Record:** record an audio file from a radio program.
- **Append:** combine two recorded files into one single file (only for files recorded in AMR format).
- **File list:** view the recorded audio files.

E-mail

You need to create and activate an email account before sending or receiving emails.

- **Inbox:** view e-mail received
- **Outgoing:** view outgoing e-mail
- **Sent:** view sent e-mail
- **Drafts:** view saved drafts

The available **Options** are:

- **View:** open the folder
- **Write Email:** write a new email
- **Connect:** connect to Email server
- **Retrieve Email:** send and receive email messages from the selected mailbox
- **Settings:** view and edit email account settings
- **Templates:** some ready-to-use templates are available, for various situations. You can edit/remove each template.

Tasks

You can View, Add, Edit, Search, Delete and Delete All on notes for various events (date, call, anniversary). If you have set an alarm tone for the note, at the desired time the mobile phone will ring and display the note content.

Notes

To memorize brief notes, of max 1000 characters. Just choose "**Add**" and edit your note, save it by pressing "**OK**". Notes can be edited and deleted.

eBook Reader

At the start the application will show the currently available ebooks list. If there are any e-books previously saved, select **Options**, then **Global Settings > Storage** and select the file path.

When you get the list of available e-books, select a file to read it, or choose **Options**:

- **Find/Find Next:** search for a word inside an ebook.
- **Jump to:** jump to a specific line in the text.
- **Go to bookmark:** jump quickly to the bookmark in the text.
- **Add bookmark:** add a bookmark in the text.
- **Delete bookmark:** delete a bookmark from the text.
- **Text info:** show detailed information on the selected ebook.
- **Settings:** set font size, scrolling mode, auto scroll, scroll speed, full screen view, alignment and character encoding.
- **Apply global settings:** apply the chosen settings.
- **Help:** show the instructions for the use of the shortcuts. Use key **0** to go to text settings screen; use key **1** for

help; use key **2** to add a bookmark; use key **3** to go to "Find" screen; use key **4** to go to "Jump to" screen; use key **5** to go to the bookmark; use key **6** to find the next occurrence of a word; use key **7** to toggle the auto scroll; use key **8** to delete a bookmark; use key **9** to toggle full screen mode.

- **Close:** close the selected ebook.

Calculator

- After inserting your first number, use the upper direction key for "+" and the lower direction key for "-", the left direction key for "x" and the right direction key for "÷", then insert your second number;
- Press $\boxed{\times}$ key to clear the latest inputs or results digit by digit; press the same key longer to clear all content or result;
- Press "=" key to obtain the result.

Nota: la precisione di questa calcolatrice è ridotta, e il suo uso va limitato a calcoli semplici.

Giochi

The phone is provided with two preloaded games (**Gold Miner** and **Air Conflicts**). For further details, please refer to the instructions included with the game (**Help**).

Coffer function

Insert ***0000#** (default value, freely editable) from call screen and access a private area of your phone, where you will find the following options: **Coffer Phonebook**, **Coffer Messages**, **Coffer Call Log**, **Change Coffer Lock**, **Block Incoming Calls**, and **Password Reminder**.

Coffer function is useful for storing contacts, SMS, call logs, etc., which you prefer to conceal from others.

The Coffer password insertion works only from the standby screen.

The contacts saved in the Coffer and the SMS coming from them as well as the whole call log, will be stored in the coffer only, and no trace of them will be visible outside of it.

The features of Phonebook, SMS, MMS, etc. inside the coffer are quite the same of the corresponding items in the "public area" of your phone.

Coffer Phonebook

The Coffer Phonebook stores up to 50 contacts. The contacts may be saved with their real names and real phone number, and, simultaneously, with nicknames and fake numbers. When receiving a call from a number inserted in this area, the phone will display the nickname of the caller, and his/her fake number.

Quick search

Display all the contact stored in the Phonebook. Selecting a contact you can open the Options: Send SMS, Call, View, Edit, Delete, Delete all, Save. Saving a contact equals to moving it into the Phonebook out of the Coffer.

If the contact has a fake name or a fake number, they will be shown on the screen.

Add entry

Here you can add name, number, nickname or fake number. The contacts can be added manually, or retrieving them from the "public" Phonebook.

Note: if a fake name/fake number has been set up, it will be displayed for incoming calls, outgoing calls and SMS sent or received; otherwise it will be displayed "**Unknown contact**".

Settings

Memory Status : show the current status of the phonebook memory (100 entries max.). The display format for the memory usage is "used/total".

Delete all: delete all the contacts from the Coffer phonebook.

Incoming call tone mode: enable/disable the tone for the incoming calls of the Coffer area.

Coffer messages

Write message

Write a new text message, and send it via SIM1 or SIM2. Each message may be up to 1140 characters in length.

Inbox

Here you can view the messages received.

Reply: reply the selected SMS.

Edit: edit the SMS to forward it later.

Delete: delete the selected SMS.

Delete all: delete all the received SMS.

Note: when selecting a contact in Coffer area to send a SMS, only the contacts saved in the Coffer phone book will be displayed.

Tip: if you receive new messages when the folder Inbox is full, the phone will automatically overwrite old messages.

Drafts

This folder shows the drafts that have been saved.

Outgoing

If you decide to select the option "**Save**" and send the message at a later time, the message will be saved in the Coffers "**Outgoing**" folder.

Outbox

This folder shows a list of sent messages (up to 10 SMS). When sending a message you can select the option "**Save and send**", the message will be saved in the Coffers "**Outbox**" folder.

Coffer SMS Tone Mode

Enable/disable the tone for the incoming SMS of the Coffers area.

Coffer Call log

These logs contain records of missed calls, received calls and dialled calls with Coffers phonebook contacts. From one of these lists, press Send key to call the selected number. Select Delete call logs to delete all the records.

***Tip:** if your phone displays a notification of missed call, press "**Read**" to immediately open the Missed calls list. If a fake name/fake number has been set up, it will be displayed in the call logs.*

Change Coffers Lock

Use this option to change the Coffers password: digit the default password first, and then the new one for two times. For instance, digit ***0000#** first in the stand-by screen; then choose Change Coffers Lock, digit the old code "**0000**", and then the new one ("**1111**", for example). You will be required to enter your new password again, then the change will take effect. The next time you access the Coffers area, you'll have to digit ***1111#** in the stand-by screen.

***Note:** do not ever forget your Coffers lock; otherwise, you will be prevented from accessing the Coffers area and your data will be lost.*

Block incoming calls

You can choose to block all the calls coming from Coffers area contacts.

Password reminder

Use this option to save and store strictly personal numbers as bank accounts, credit cards, ATM codes, various passwords, etc.

T9 Text input

Text input methods

The mobile phone provides multiple convenient input modes, with support of other functions. Besides the standard mode, you have the opportunity to use the T9 method (set as default method), a system for predictive text entry.

Basic letter input

Use the key to switch between "**IT / it / It**", e "**T9 IT / T9 it / T9 It**"; input the desired letters with the standard keyboard.

Numeric input (123)

This mode is primarily used to enter telephone numbers, codes, etc.

Symbol input

Choose this mode by pressing the key “.,?!”,;”; you can then access to the symbol library and insert the desired one where the cursor is blinking.

Insert capital / lower case letters

Change the input mode through “↓a” an “↑A”.

USB connection

- Always make sure you connect and stop any USB devices correctly.
- Never use Windows formatting command to format the mobile disk of the mobile phone; otherwise, it could be severely damaged.
- USB work environment:
 - Minimum Operating System: Windows 2000 / XP .
 - Other operating systems could require the installation of a USB driver for PC/phone connection.

Maintenance and Safety

Please read and observe the following information for a safe and proper use of your phone and to prevent damage. Keep this User Guide in an easy to find place. When you need a quick reminder on how to respond to a particular situation, go to the relevant section for the information you need.

Post-sale service

For details, please refer to the Guarantee Certificate or Warranty Card inside the box.

Charger and adapter

Charger and adapter are designed for indoor use only. Do not use them in wet environments.

Battery Information and Care

- Please dispose of your battery properly.
- Do not disassemble or short-circuit the battery.
- Keep the battery’s metal contacts clean.
- Recharge the battery after long periods of non-use to maximize battery life.
- Battery life could vary due to usage patterns and environmental conditions.
- The self-protection function of the battery cuts the power of the phone when its operation is in an abnormal status. In this case, remove the battery from the phone, reinsert it, and turn the phone on.

General Notice

- Using a damaged battery or placing a battery in your mouth may cause serious injury.
- Do not place items containing magnetic components such as a credit card, phone card, bank book, or subway ticket near your phone. The magnetism of the phone may damage the data stored in the magnetic strip.
- Talking on your phone for long period of time may reduce call quality due to heat generated during use.
- When the phone is not used for a long period time, store it in a safe place with the power cord unplugged.
- Using the phone in proximity to receiving equipment (i.e. TV or Radio) may cause interference to the phone.
- Do not immerse your phone in water. If this happens, remove the battery and take it to nexian Authorized Service Center.
- Do not paint your phone.
- The data saved in your phone might be deleted due to careless use, repair of the phone, or upgrade of the software. Please backup your important phone numbers. (Ring tones, text messages, voice messages, picture, and videos could also be deleted.) The manufacturer is not liable for damage due to the loss of data.
- Do not turn your phone on or off when the device is close to your ear.

Troubleshooting

Before contacting after-sales service, perform the following simple checks. They may save you the time and expense of an unnecessary service call.

Problems	Possible Causes
Unable to switch on	<ol style="list-style-type: none"> 1. Does the battery have enough electrical power? 2. Is the battery placed correctly?
SIM failure	<ol style="list-style-type: none"> 1. The SIM card is dirty. Clean it. 2. Reinstall the SIM card. 3. The SIM card is damaged. Replace it.
Poor signal	Check the signal strength icon on the screen. If the icon contains 4 bars, the signal is at its strongest; if it is below 1 bars, the signal is very poor. You may be in a weak reception area. Move and try again
Unable to dial out	<ol style="list-style-type: none"> 1. Maybe you have set Hide My Caller ID but your network operator does not provide this service for you. 2. There are lots of interference sources in your neighborhood. 3. Maybe you have activated some call restriction function.
Unable to charge the battery	<ol style="list-style-type: none"> 1. The battery may be over-discharged; so it requires a longer charging period than normal. 2. Its performance has got worse; it is necessary to replace the battery.
Unable to register to the network	<ol style="list-style-type: none"> 1. Too weak signals or strong interferences. 2. SIM card not properly installed. Bad contact or SIM card damaged. If the SIM card is broken, please contact the network operator to replace it.
No ringtone on incoming calls	<ol style="list-style-type: none"> 1. The Silent profile has been selected in User Profiles. 2. The ringtone volume is too low. Set the correct volume through User Profiles.
The phone prompts you to enter your PUK code	The incorrect SIM PIN has been entered more than 3 times and the SIM is now locked. Please contact the network operator.
Photos taken are too dark	<ol style="list-style-type: none"> 1. Brightness is set too low. 2. Ambient light is poor.
Photos taken are unclear	<ol style="list-style-type: none"> 1. Check if your subject is moving too fast. 2. Maybe the phone slightly moved while the shutter was open.
Photos taken are distorted	The subject may be too close for the camera lens.
The picture selected as wallpaper is only partially visible	The size of the photo is probably too large.
Service menu is not accessible	Maybe your SIM card doesn't support Services function.
Unable to switch on	<ol style="list-style-type: none"> 1. Does the battery have enough electrical power? 2. Is the battery placed correctly?

Abbreviations

SMS	Short Message Service
MMS	Multimedia Message Service
EMS	Enhanced Message Service
SIM	Subscriber Identity Module
GSM	Global System for Mobile Communication
PIN	Personal Identity Number
PUK	PIN Unblocking Key
IMEI	International Mobile Equipment Identity
CSD	Circuit Switched Data
USSD	Unstructured Supplementary Service Data
APN	Access Point Name
CB	Cell Broadcast
GPRS	General Packet Radio Service
UART	Universal Asynchronous Receiver/Transmitter
Card 1	SIM Card principale (la card inserita nello slot SIM1)
Card 2	SIM Card secondaria (la card inserita nello slot SIM2)

Certifications

Declaration of conformity (R&TTE)

We, **NGM Italia**

declare under our sole responsibility that the product identified as:

GSM Mobile Phone: **Soap EVO**

conforms to the following standards and specifications:

Health	EN 50360, EN 62209-1
Safety	EN 60950-1+A11
EMC	EN 301 489-1/-7/-17
Radio	EN 301 511 EN 300 328

We declare that [all the series of fundamental radio test have been conducted and that] the aforesaid product meets all the essential requirements of the Directive 1999/5/EC.

The conformity assessment procedure referred to in Article 10 and detailed in Annex IV of Directive 1999/5/EC has been followed with the involvement of the following notified bodies:

PHOENIX TESTLAB GmbH
Königswinkel 10,
D-32825 Blomberg,
Germany



All technical documents conserved at NGM Italia S.r.l.

Available on request.

(UE Authorized Representative)

NGM Italia S.r.l.

Via L. Da Vinci, 7 – Ponticelli

56020 Santa Maria a Monte (PI)

S.A.R. (Specific Absorption Rate)

SAR certification information

Cell phones are radio transceivers. They have been projected not to exceed the radio wave exposition limits recommended by international guidelines. These guidelines have been determined by the international independent scientific organizations ICNRP and IEEE and include security limits to ensure protection to all persons, independently from their age and health conditions.

This phone meets European Union (EU) requirements concerning exposure to radio waves coming from telecommunication and radio devices. The exposure standard for mobile phones employs a unit of measurement known as SAR (Specific Absorption Rate). The SAR limit recommended by the EU Council is 2.0 W/kg averaged over ten grams of body tissue.

The highest SAR value for this model phone when tested for use at the ear was 1,313 watt/kg [1,2]. Although the SAR is determined at the highest certified power level, the actual SAR of the phone while operating can be well below the maximum value. This is because the phone is designed to operate at multiple power levels so as to use only the power required to reach the network. In general, the closer you are to a base station, the lower the power output of the phone. The Declaration of Conformity here above proves that the designated product is in compliance with the essential requirements and other relevant provisions of the R&TTE - Directive (European Radio & Terminal Telecommunications Equipment)1999/5/EC.

[1] These controls have been made according to international guidelines on controls.

[2] For the use next to the body, this telephone model has been controlled and is conform to the directives for the exposition to electromagnetic radiation, when used with accessories provided by or approved by NGM and not containing metallic parts and that position the mobile phone at least at 1,5 cm distance from the body.

Warnings

WHO (World Health Organization) confirms that the actual scientific information does not indicate the necessity to adapt particular precautions for the use of cell phones.

Nevertheless, for all those users not comforted by these data, NGM advises to limit their own and their children's exposure, for instance by reducing the calling time, or by using earpieces or hands-free devices to keep the mobile phone distant from the body and the head.

For more information on the argument, NGM invites to consult the WHO document (Fact sheet N°193, June 2011) entitled Electromagnetic fields and public health: mobile phones at the following web address:

<http://www.who.int/mediacentre/factsheets/fs193/en/index.html>

NGM advises to use mobile devices of any brand or model with moderation and to keep them at a minimum distance of 1,5 cm from the body or to use earpieces or other hands-free devices.

